

TWISTER STOVETOP POPPER USING YOUR STOVETOP POPPER

Using Your Twister

Once the popper meets the heat your popping time should be around 3 minutes, though depending on the heat source, popping time may vary. As you become more familiar with your popper you will be able to adjust your heat source to approximate a 3 minute total popping time. Here are some general guidelines depending upon your stovetop:


- Flat top ranges are generally hotter than other heat sources, so set your flat top to medium-low/medium.
- Set your electric stovetop to medium/medium high.
- Set your gas stovetop burner to medium.
- The Twister is for household use only. To cook over a campfire or open flame, use our Pit Popper.

1. Add ingredients to the popper before placing on your stove, flat top or electric burner. Use about 2T. of oil to 1/2c. corn, though you may want less or more oil depending on your tastes.
2. Turn the Twister's handle steadily until the popping slows or stops or it becomes very resistant to turning.
3. Use the wooden knob on the left, or unlocked side, of the popper to pour popcorn into a bowl...season and serve immediately. **CAUTION!** Popcorn will be hot. We recommend using hot pads to avoid steam burns. Use caution when unloading your kettle.



WARNING

Popper is extremely hot during and after use! Take care to keep hot popper away from children. DO NOT TOUCH HOT POPPER. REMOVE TO A SAFE PLACE UNTIL COOL



CAUTION: Pot, oil and popcorn are extremely hot. Escaping steam can cause severe scalding. Children and many adults are naturally attracted to the excitement of the popping event. Keep children and others well back out of harm's way.