

babycook® pro

Quick Start Guide



1. Use the measurement markings on the Bowl to measure out how much water you need for the recipe you are making (See Water Level Chart).



2. Pour the water into the Water Reservoir by placing the lip of the Bowl on the upper edge of the Reservoir. Do not leave any water in the clear Bowl.



3. Fill the Cooking Basket with chopped food, place the Basket into the clear Bowl.



4. Place the Bowl on the Base. Lock the Bowl onto the Base by turning the Bowl counterclockwise. Press down on the Lid to close and lock.



5. Plug in your Babycook appliance and press the Steam Button. A light and a sound will signal when the cooking cycle starts.



6. When cooking is complete, (maximum 15 minutes depending on water level) an audible alert is heard and the Steam Symbol on the button flashes. To stop the flashing, press the button again.



7. Release the Lid and remove the Basket using the Spatula. You may choose to keep the cooking liquid in the Bowl or discard it at this time, depending on how thin or thick you would like the purée.



8. Empty the food into the Bowl. Place the Mixing Cover horizontally over the Bowl using the Spatula.



9. Lock the Lid into place and pulse the dial to the right (maximum 10 seconds) to blend.