

Troubleshooting Steps

- Place the range extender half way across the router where you get at least 50-60% of good Wi-Fi coverage from your main router.
- Factory reset the range extender and configure it back again to the router, making sure it is configured properly with a different SSID compared to main router.
- Try changing the Wireless channel on router which will help in signal dropouts.
- Also make sure the range extenders firmware is up to date.
- Place the Range extender at an elevated position for best Wi-Fi reception and also if the RE equipped with antennas, they should be positioned properly.