

Instruction Manual

Product ID 757-C337 Product Name Gesture Remote Control Car

Remote Layout

(The watch remote control use with one cr2025 button cell) button cell is non-rechargeable battery, please change battery if the power runs out

Watch Sensor Control

1. Fist rises vertically, body twist rises
2. Fist goes down vertically, body twist is reduced
3. Fist leaned forward, the car forward
4. Fist leaned back, the car backed
5. Fist leaned left, the car drifted left / rotated counterclockwise in place
6. Fist leaned right, the car drifted right / rotated clockwise in place
7. Short press the finger button to switch modes (horizontal run / rotate), long press to mute

2.4G Automatic pairing frequency

1. Install the batteries in the remote control, and the remote control indicator will start flash. Then install the battery in the rc car and turn on the switch to start the connection. When the connection is successful, the remote control indicator goes off. (Please repeat the above operation if the connection fails)
2. Each remote control can only be connected to one rc car. When the connection is successful, each car will not interfere with each other. (Do not connect multiple cars at the same time)
3. If the remote control does not detect the 2.4G signal from the remote control car after one minute, the power indicator flashes, you must restart the power switch to pair the frequency.
4. When you need to pair with other models of remote control or remote control car, you need to turn off the power of the remote control and remote control car to re-pair.

Precautions

The battery charger using this toy must be checked regularly to prevent damage to the wires and other parts. If it is damaged, it must be used after the damage is repaired

Watch Sensor Control Demo

1. Fist rises vertically, body twist rises

2. Fist goes down vertically, body twist is reduced

3. Fist leaned forward, the car forward

4. Fist leaned back, the car backed

5. Fist leaned left, the car drifted left / rotated counterclockwise in place

6. Fist leaned right, the car drifted right / rotated clockwise in place

Battery Installation Instructions

The remote control uses two 1.5V (AA) non-rechargeable batteries. Please install the batteries correctly according to the polarity instructions. (Battery is not included)

Battery socket to body power socket

Charging Instructions

Input: 5V
Output: 3.7V

1. To protect the performance of the battery pack, do not charge the battery pack immediately after use. Leave the battery pack for a few minutes before recharging.
2. The USB charger indicator is on during charging, and the indicator is dimmed after charging. The charging time is about 2-3 hours.
3. It is normal for the battery pack to generate slight heat during charging.

RC Car Operation Instructions

1. Turn on the remote control car switch
2. Operate the remote control's arrow keys to control the direction of the car
3. Turn off the remote control car switch after use
4. One-click deformation. When the deformation key is pressed, the car will automatically deform
5. If the remote control car does not receive a command for one minute, it will enter the semi-sleep state (the semi-sleep state is not equal to shutdown, only the power consumption is reduced), and the lights and sounds are turned off. After entering the semi-sleep state, you can wake up by any operation of the remote control.
6. If the remote control is not connected to the remote control car for one minute, it will automatically enter the sleep state. You can wake up with any button.

Note: The battery has low voltage protection. It will automatically power off when the voltage is low, and it can be activated after charging.

Battery Precautions

1. This product uses one 3.7V rechargeable battery pack. The remote control uses two 1.5V "AA" non-rechargeable batteries.
2. The battery should be taken out and installed correctly according to the polarity and voltage signs on the toy battery box, and the battery should not be short-circuited.
3. Non-rechargeable batteries cannot be charged.
4. The rechargeable battery must be charged under adult supervision.
5. The rechargeable battery should be removed from the toy before charging.
6. Different types of batteries or old and new batteries cannot be mixed.
7. Only use the same or equivalent batteries as the recommended ones.
8. The exhausted battery should be removed from the toy. If not used for a long time, please remove the battery from the toy.
9. The power terminals should not be shorted.
10. Do not connect to more than the recommended number of power sources.

During the use of the toy USB cable, it should be regularly inspected for damage to its wires, plugs, casings and other components. When damage is found, it should be stopped until repaired.

General Troubleshooting		
Malfunction Condition	Cause of Malfunction	How to Deal with
Car Doesn't Work	1. The remote control is not connected or the switch of the remote control car is not turned on. 2. The remote control or remote control car is not properly installed the battery. 3. The rechargeable battery pack has insufficient power.	1. Turn on the remote control car switch and reconnect the remote control. 2. Install the battery into the remote control or remote control car correctly. 3. Charge the rechargeable battery pack.
Uncontrolled Car Near Remote Control Distance	1. The battery in the remote control or rechargeable battery pack is low. 2. There may be interference sources near the site.	1. Replace the batteries in the remote control with new batteries or charge the rechargeable battery pack. 2. Change the site.

Customer Service

If you have any problem or confuse, please send us following information. We will do our best to help you.

1. amazon order ID
2. issue with picture or video
3. address with postal code

Email: NQD_customerservice@outlook.com (Rose Red/Green Color)
Email:nqd_serviceteam@126.com(Blue Color)

Rose Red/Green Color

Blue Color