

SECURA®

COOL TOUCH ELECTRIC WATER KETTLE

USER INSTRUCTIONS

Seamless Stainless Steel Interior-Healthy Water
Cool Touch Exterior-Safe To Use

Model: SWK-1701DB / SWK-1701DR / SWK-1701DW / SWK-1701DP / SWK-1701DO / SWK-1701DA



SN: 32QJ

www.thesecura.com



Welcome to the Secura Family!

Congratulations on being the proud owner of your new Secura product. We believe in manufacturing only the highest quality kitchen, home and personal care products for our customers. We are a U.S.-based manufacturer and all our products meet strict standards for manufacturing, safety and performance.

We also believe in providing the best customer service and support in the industry. That is why we offer a 2-year warranty on this product that ensures your satisfaction - so you can enjoy it for years to come.

If you have any questions or need assistance, please email CustomerCare@thesecura.com. For fastest response, please include product name and model #, proof of original purchase, complete contact information, and detailed information about the issue, including pictures when applicable.

Your feedback and suggestions are also important to us, so please email them to us at CustomerCare@thesecura.com.

The Secura Team

SECURA®

Copyright 2016-2022 Secura, Inc. All rights reserved.

The material in this publication is protected under International and Federal Copyright Laws and Treaties, and as such, any unauthorized reprint or use of this material is strictly prohibited.

No part of this book may be reproduced or transmitted in any form without the written permission of the author, except for the inclusion of brief quotations in a review.

Reproduction or translation of any part of this work without the express permission of the copyright holder is against the law.

TABLE OF CONTENTS

IMPORTANT SAFEGUARDS	1
PARTS DESCRIPTION	4
OPERATING INSTRUCTIONS	5
CLEANING AND MAINTENANCE	8
STORE YOUR APPLIANCE	9
TECHNICAL INFORMATION	9
DISPOSAL	10
CONTACT	10
MANUFACTURER'S LIMITED WARRANTY	11

IMPORTANT SAFEGUARDS



To reduce the risk of electrical shock, fire or injury, and to extend the life of your product, please read and observe all information in this manual prior to and while using your product. Please save this manual for future reference.

When using this kettle, always follow the safety precautions listed below:

- Read all instructions before using this kettle.
- For personal use only and not for use in a commercial setting.
- Do not use in any way other than its intended use.
- Do not operate outdoors or in any type of wet or extreme conditions.
- For added safety, this kettle should always remain unplugged when not in use.
- Do not use the kettle if the plug, the power cord, or the kettle is damaged. Do not attempt to operate or repair if damaged or if the product malfunctions in any way. Contact our customer service department at CustomerCare@thesecura.com or 888-792-2360 for additional information.
- Use of an extension cord is not recommended. However, if required, the electrical rating of the cord must be equal to or greater than the electrical rating of this kettle.
- Always use and store on a flat, level, stable surface, away from any ledge and out of direct sunlight.
- Do not place the kettle or the power cord on or near a stove top, open flame or other heated surface.
- Do not operate using an external timer, remote control or smart system.
- To allow optimal airflow and avoid overheating, always allow at least a 4-inch clearance on all sides when in use and while cooling down.
- Carefully position the power cord so no one can become entangled in the cord and so that the cord is not a tripping hazard.
- Place the kettle on its base before plugging the power cord into an outlet. Do not plug the power cord into an outlet until the kettle is filled, closed and ready to use.
- This kettle is used for boiling water. Do not fill with anything other than drinking water in normal use, except for descaling.
- Do not brew tea or other beverages in the kettle as that can change the boiling characteristics of water and may cause overflowing.
- Do not operate when empty or without the minimum required water level (0.5-liters / 2-cups) or damage can occur.

SECURA®

- Do not fill above the maximum level indicated (1.7-liters / 7-cups). Overfilling can cause the boiling water to overflow.
- Do not leave unattended while operating.
- Do not leave the lid open or press the lid release button while operating to avoid the risk of burns or scalding. The lid must remain closed while operating to allow the internal sensor to function correctly. Failure to do so may result in overheating, water boiling over and damage to the kettle.
- Never allow children to operate, have access to, or leave them unsupervised near this kettle.
- To reduce the risk of burns or scalding, use caution when handling during and immediately following use.
- This kettle may release heat, steam, condensation and hot water during and after operation. Use extreme caution when handling to prevent the risk of burns, scalding or other injuries and damage to property.
- The use of third-party accessories or attachments or any parts not designed specifically for this model, may result in fire, electric shock, or injury and damage to property or kettle.
- Ensure that the switch is in the OFF position after every use.
- Always unplug and allow to cool before moving, disassembling, cleaning or storing.
- Never immerse the kettle, base or power cord in liquid or expose to other wet environments.
- Never place the kettle or base in the dishwasher.
- Always follow the cleaning methods recommended in this manual. Never use harsh chemicals or abrasive materials to clean any part.
- All parts should be completely dry before assembling, using or storing.
- Do not dispose of with regular municipal waste. Use a designated collection facility. Contact your local waste management or regulatory agency for information regarding disposal options.



CAUTION:

Only connect to a properly grounded outlet to prevent the risk of electric shock.



CAUTION:

To avoid circuit overload, do not operate another high wattage appliance on the same outlet or circuit.



WARNING!

The kettle and base are NOT dishwasher safe. Do not place in the dishwasher or submerge in liquid.



Always follow basic safety precautions when using any electrical products, especially when children are present.




CAUTION: HOT SURFACES!

This appliance generates heat and releases steam during use. Proper precautions must be taken to prevent the risk of burns, fires or other injury to persons or damage to property.


FOR HOUSEHOLD USE ONLY

SAVE INSTRUCTIONS FOR FUTURE REFERENCE

PARTS DESCRIPTION



1. Lid Release Button
2. Spout
3. Kettle Body
4. Power Base
(cord storage under base)
5. Lid
6. Handle
7. Illuminating ON/OFF Switch
8. Power Cord



NOTE: There is only 1 rubber foot pad built into the base. This is a safety feature as 1 pad helps to prevent the base from sliding, while allowing it to “pivot” if the kettle is knocked.

FEATURES

- One-touch illuminating ON/OFF switch for easy use
- Shuts off automatically for worry free use
- Boils 0.5-liters to 1.7-liters (2-cups to 7-cups) of water in minutes
- Seamless uni-body interior made from high quality, 18/10 stainless steel which is rust, corrosion and odor resistant
- Cool Touch exterior and handle makes the kettle safe to touch even when boiling
- Strix Technology Kettle Controls - the world's leader in kettle controls
- Wide top opening for easy filling and easy cleaning
- Boil Dry Protection Sensor protects and extends the life of your kettle
- Classic design complements any decor
- Easy to clean exterior is smudge and fingerprint resistant
- Convenient under base storage for power cord

OPERATING INSTRUCTIONS

SAFETY INSTRUCTIONS

- Carefully remove your product and all documentation from the box. Storing your product in its original box helps to protect it while not in use.
- Always use and store on a flat, level, stable surface, away from any ledge and out of direct sunlight.
- The power cord is stored on the underside of the base. For safety reasons, only unwind enough of the power cord to reach the outlet and keep the power cord stored underneath when not in use.
- Position the base so no one can become entangled in or trip over the power cord.
- Remove the kettle from the base before filling or pouring.
- Use purified or deionized water, when possible, to minimize mineral build-up in the kettle.
- This kettle is used for boiling water. Do not fill with anything other than drinking water in normal use, except for descaling process.
- Do not brew tea or other beverages in the kettle as that can change the boiling characteristics and may cause overflowing.
- If water drips onto the base, wipe dry before placing the kettle on the base.
- Never touch the interior of the kettle or lid during or immediately following use. The exterior body and the handle will remain cool, however touching the stainless steel interior can result in burns or scalding.
- Do not attempt to use the kettle without the lid locked securely in the closed position.
- Do not press the LID RELEASE button while operating.
- The kettle turns off automatically when removed from the base.
- Be careful of steam coming from the spout, especially while pouring or if adding water immediately after boiling.
- Allow kettle to cool completely before opening lid to avoid hot condensation.
- Pour slowly and do not over-tilt to avoid the risk of splashing
- The Boil Dry Protection Sensor turns the kettle off automatically when it detects that the kettle is empty. If the Boil Dry Protection feature is activated, please allow the kettle to cool down at least 15 minutes before refilling.

KETTLE PREPARATION

Preparing your kettle for first time use:

1. Remove the kettle from the base.
2. Press the LID RELEASE and fill the kettle with cold water until it reaches the interior MAX line.

3. Close the lid, place the kettle onto the base and plug the power cord into an outlet.
4. Press the ON/OFF switch into the ON position. The switch will illuminate and remain on until the water comes to a boil (212°F). Once the water boils, the kettle shuts off automatically in approximately 20 seconds, the indicator light turns off and the ON/OFF switch returns to the OFF position.
5. Carefully remove the kettle from base and discard the water. Allow kettle to cool completely before opening lid to avoid hot condensation.
6. Repeat steps 1-5 again to remove any production residue from the interior of the kettle.
7. Unplug the power cord and allow the kettle to cool completely.

NOTE: Do not consume the water used during the preparation process. It should be discarded immediately. While not harmful, this is the initial cleaning process and the water may taste unpleasant.

USING YOUR KETTLE

1. Remove the kettle from the base.
2. Press the LID RELEASE and fill the kettle with cold water until it reaches the correct amount between 0.5-liters (2 cups) minimum and 1.7-liters (7 cups) maximum.
3. Close the lid, place the kettle onto the base and plug the power cord into an outlet.
4. Press the ON/OFF switch into the ON position. The switch will illuminate and remain on until the water comes to a boil (212°F). Once the water boils, the kettle shuts off automatically in approximately 20 seconds, the indicator light turns off and the ON/OFF switch returns to the OFF position.
5. Carefully remove the kettle from the base and pour water as needed. Allow kettle to cool completely before opening lid to avoid hot condensation.
6. Return the kettle to the base.
7. To reheat the water, refill if required and repeat steps 3 – 6.
8. Unplug the power cord when done and allow the kettle to cool completely.

BOIL DRY PROTECTION FEATURE

If the kettle is empty or contains less than 0.5-liters (2 cups) of water, the BOIL DRY PROTECTION SENSOR will activate, and the kettle will shut-off automatically. This protects the kettle from damage due to overheating.

If this happens, please do the following:

1. Lift the ON/OFF switch into the OFF position, if needed.
2. Unplug the base.
3. Wait at least 10 minutes for the temperature sensor to reset before attempting to use the kettle.

WARNING!



The sensor reset process is designed to protect the heating element and extend the life of your kettle. Do not attempt to cool the kettle faster by filling with cold water or by any other method. Doing so will reduce the life span of the kettle's heating plate.

IMPORTANT!

You may see some discoloration on the bottom of the stainless steel kettle interior over time. This is harmless and expected due to the bonding of the heating element to the kettle floor.

Clean the stainless steel kettle interior using Barkeeper's Friend Cleanser and Polish. Refer to the "Cleaning and Maintenance" section of this manual.

CLEANING AND MAINTENANCE

NOTE: Always unplug the base from outlet and let kettle cool completely before cleaning.

Exterior Cleaning:

- Use a soft damp cloth to wipe the exterior. Do not use any abrasive cleansers or scouring pads as this will damage or scratch the surface.
- Clean the base with a damp cloth.
- Keep all connectors and sockets dry.

Interior Cleaning:

The interior of the Secura water kettle is made of high quality stainless steel. There is no plastic in contact with hot water, which provides you with safe daily use. To ensure that your kettle enjoys a substantially longer life and operates at maximum efficiency, we do not apply any coatings, since they can peel off or wear away. Cleaning is something that should be done regularly. We suggest that owners rely on Bar Keepers Friend Stainless Steel Cleaner & Polish to keep the stainless steel interior in top condition. We also recommend the use of purified or deionized water for the least amount of mineral build-up on the interior.

- To remove stubborn spots/marks on the interior, wipe the surface with a slightly dampened cloth and a small amount of Bar Keeper's Friend or other mild, non-abrasive stainless steel cleaner (following the instructions on the container). Rinse with water and wipe dry with a clean soft cloth.
- Do not use harsh or abrasive cleaning agents or solvents.
- Do not open, change or service any parts yourself.

Removing Mineral Build-Up

Depending on the mineral content (also known as "hardness") of the water you use, mineral build-up may occur on the inside of your kettle. This is normal even when using filtered water. For optimal performance, we recommend removing the mineral build-up. This can be done using the following decalcifying process:

1. Add 3.5 cups plain water to the kettle.
2. Replace the lid and place the kettle on its base. Plug the power cord into an outlet and following the kettle's operating instructions for boiling water.
3. Once the water boils and the kettle switches off, unplug the power cord from the outlet.

Warning: Hot condensation may accumulate in the lid. Use extreme caution when opening the lid to avoid burns and scalding.

4. Add 3.5 cups of white vinegar to the kettle. Hot vinegar-water mixture provides better descaling results. Make sure the mixture does not exceed the MAX line. Allow the mixture to soak overnight.

Warning: DO NOT plug in the kettle to heat or boil again after adding vinegar to the water, as the mixture will spill out of the kettle which could result in burns and damage.

5. Carefully empty the kettle. Wipe the interior with a soft cloth, then rinse with water.

6. To make the interior of the kettle vinegar-free, fill the kettle with plain water until it reaches the interior MAX line and boil the water. After the kettle switches off carefully discard the water.

7. Once the kettle has cooled, dry thoroughly with a soft cloth.

STORE YOUR APPLIANCE

- Unplug the unit from the wall outlet and clean all the parts as instructed above. Ensure that all parts are dry before storing.
- Store the appliance in its box or in a clean, dry place.
- Never store the appliance while it is still wet or dirty.
- Never wrap the power cord around the appliance.

TECHNICAL INFORMATION

Model	SWK-1701DB / SWK-1701DR / SWK-1701DW / SWK-1701DP / SWK-1701DO / SWK-1701DA
Rated Voltage	120V 60HZ
Rated power input	1500W
Capacity: Max	1.7 Liter /1.8 Quart
Product Dimension	9" x 6.5" x 11" / 23cm x 16cm x 28cm
Package Dimension	8.1" x 7.5" x 10.5" / 20.3cm x 18.8cm x 26.7cm

DISPOSAL



When the appliance has reached the end of its life, please be responsible with its disposal. This and other electrical appliances contain valuable material and can be dangerous to the environment if not disposed of properly. We ask that you follow the rules and regulations of your town as far as disposing of electric appliances. Please endeavor to take the appliance to an authorized recycling facility near you.

CONTACT

If you have any questions or need assistance with this item, please contact our customer service department at 888-792-2360 (North America) or CustomerCare@thesecura.com

Please read operating instructions before using this product.

Please keep the original box and packaging materials in the event that service is required.

SECURA®

Manufacturer's Limited Warranty

The Manufacturer of this product warrants to the original purchaser of this product that this product will be free from defects in material and workmanship under normal use and service for 2 years from date of purchase. Manufacturer will, at its option, repair or replace with a new or refurbished product. The Manufacturer reserves the right, before having any obligation under this limited warranty, to inspect the product, and all costs of shipping the product for inspection and warranty service shall be borne solely by the purchaser.

For the fastest processing of a warranty claim, the Purchaser should e-mail CustomerCare@thesecura.com and include the product name and model #, proof of original purchase, complete contact information, and detailed information about the issue, including pictures when applicable.

The manufacturer's limited warranty is valid only in accordance with the following conditions:

1. The product is purchased directly from manufacturer or an authorized reseller or distributor.
2. Only the original purchaser is covered by this warranty. This warranty is not transferable.
3. Product is for personal use only. This warranty is void if the product is used in a commercial or institutional establishment.
4. This warranty does not cover normal wear and tear or damage caused by misuse, abuse, negligence, accident, acts of nature, or unauthorized modification or repair.
5. Purchaser must present acceptable proof of purchase for the product.
6. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Secura, Inc.
CustomerCare@thesecura.com
Lake Forest, California

SECURA®

Secura Bestsellers

Secura 60-Minute
Visual Timer



Secura Electric
Wine Opener



Secura Electric
Soap Dispenser



Secura Premium
Wine Aerator



Secura Electric Coffee
and Spice Grinder



Secura Automatic
Milk Frother



Duxtop Whole-Clad Tri-Ply
Premium Cookware



Secura French Press
Coffee Maker



Duxtop Portable 1800W
Induction Cooktop



Secura 1700W Electric
2-in-1 Grill Griddle



Secura Triple Basket
Electric Deep Fryer



Secura Electric
Hot Air Fryer



Secura, Inc.

888-792-2360 (North America)

CustomerCare@thesecura.com

www.thesecura.com

Lake Forest, California

For the fastest processing of a warranty claim, the owner should e-mail CustomerCare@thesecura.com and include the product name and model #, proof of original purchase, complete contact information, and detailed information about the issue, including pictures when applicable.