

⚠ IMPORTANT SAFETY INSTRUCTIONS

WARNING: Never leave the appliance unattended while in use.

CAUTION: Blades are Sharp! Handle carefully.

Avoid contact with moving parts. Keep fingers out of the chute opening.

Never feed food by hand. Always use food pusher

SAVE THESE INSTRUCTIONS

- Place the salad shooter onto the bowl and turn clockwise to lock in place on the motor base. (Fig. 1)
- Place the slinger inside the salad shooter. (Fig. 2)
- Use the finger holes to grasp the selected disc and place it over the slinger. (Fig. 2)
- Place the lid on the salad shooter and turn clockwise to lock in place. (Fig. 2) Place a bowl (not included) underneath the chute to catch all the food coming out.
- Plug the power cord into the electrical outlet and press on the power button (⏻).
- For best results, use speeds 2 or 3 when operating the salad shooter.
- Add the food that you want to slice, shred or grate through the feed chute on the lid. (Fig. 2)
- Use the assembled food pusher to push the food through the feed chute. (Fig. 2) The food will come out of the chute as it is processed. If the food to be sliced is of a small diameter, use the small feed chute by twisting the food pusher and removing the inner tube. Feed the food to be sliced through the smaller chute.
- When finished, turn the power off and remove the lid. Using the finger holes, carefully lift the disc and the slinger from the salad shooter.
- Turn the salad shooter counter clockwise and then lift off the base.
- The salad shooter, lid, food pusher, slinger and discs are all dishwasher safe.

💡 TIP: Twist the inner tube counter clockwise to unlock it from the food pusher.

⚠ IMPORTANT: The motor base is not included with this kit.

⚠ NOTE: For further instructions, please refer to the Owner's Guide.





Fig. 1

Fig. 2

