


T16

True Wireless Earbuds User Manual



Thank you for purchasing our product. This manual addresses the safety guidelines, warranty, and operating instructions. Please review this manual thoroughly before operating your device.

English Version


Package Contents.....	1
At a Glance.....	1
How to Wear.....	2
Earbuds LED Indicator Guide.....	3
Charging Case Indicator Guide.....	3
Using Your T16.....	4
FAQS.....	9
Specifications.....	11
Safety and Warranty.....	12

Package Contents


- Wireless Earbuds × 1 pair (left and right)
- Charging Case × 1
- Micro USB cable × 1
- User Manual × 1

At a Glance

Earbuds




Charging Case



Charging Pins

Micro USB Charging Port



Charging Case Indicator

How to Wear

Insert the earbud into your ear and rotate to fit comfortably.



Earbuds LED Indicator Guide

System State	Indicator Activity
Power on	The LED indicator stays blue for 1 second.
Power off	The LED indicator flashes red twice.
Pairing mode	The LED indicator flashes red and blue alternately.
Charging	The LED indicator stays red.
Fully Charged	The LED indicator goes off.

Charging Case Indicator Guide

System State	Indicator Activity
Charging	The charging case indicator flashes blue slowly.
Fully charged	The charging case indicator stays blue.

Using Your T16

Charge the earbuds


Put the earbuds into the charging case.

Note:

When your earbud battery life is low, you will hear a voice reminder.

Charge the charging case

- 1) Plug the small end of the USB cable into the Micro USB port of the charging case.
- 2) Plug the other end into a USB wall charger or computer (DC 5V) that is powered on.



Note:

It takes approximately 2 hours to fully charge the charging case. A fully charged charging case can charge the earbuds approximately 3 times.

Power on & off

Automatic operation

Power on: Open the lid of the charging case and take the earbuds out.

Power off: Put the earbuds back into the charging case.

Note:

When the charging case is out of power, putting the earbuds back in the charging case will not turn the earbuds off.

Manual operation

Power on/off: Tap and hold the touch button on the left/right earbud for 5 seconds.

Note:

When the two earbuds are paired with the phone, turn off one earbud manually will make the other one be off at the same time.

Pairing & Connectivity

- 1) Turn on the Bluetooth of your Bluetooth device.
- 2) Take the earbuds out of the charging case and they will enter pairing mode automatically and the LED indicator on the earbud will flash red and blue alternately.
- 3) Choose "T16" from the list of found Bluetooth devices on your Bluetooth device to pair.

Notes:

- Make sure the earbuds and your Bluetooth device are next to each other within 33 feet or 10 meters and there are no obstacles between.
- If pairing failed, put the earbuds back into the charging case make sure that they have been turned off. Then pair the earbuds with your Bluetooth device again.
- When the earbuds are on but not paired with a Bluetooth device, they will be automatically off after 5 minutes.
- The earbuds will connect to the last paired Bluetooth device automatically when they are turned on. Please turn on the Bluetooth of your Bluetooth device before turning on the earbuds.

Primary/Secondary mode

These earbuds have primary-secondary switch function.

- When the earbuds have been connected to a Bluetooth device, take out either of the two earbuds, it can be connected and used normally. During this period, you can take out the other one and they will pair with each other so you can use both of the earbuds.
- When both earbuds are connected to your phone, no matter which one is put back to the charging case, you can use the other one without interruption.

Earbuds functions

Function	What to do
Play/Pause	Tap the touch button of the left/right earbud.
Next track	Double-tap the touch button of the left/right earbud.
Previous track	Tap the touch button of the left/right earbud three times.

Call functions

Function	What to do
Answer/end a call	Tap the touch button of the left/right earbud.
Decline an incoming call	Double-tap the touch button of the left/right earbud.

Activate voice control of phone

After the earbuds are connected to your phone, tap and hold the touch button for 2 seconds and remove your finger from the touch button.

Tap and hold the touch button for 2 seconds again to exit. (This function works only when your phone has voice control function; please refer to the instructions of your phone for details.)

Clean the earbuds and charging case

Clean the earbuds and charging case only with a dry, soft cotton swab or equivalent.

FAQS

Q1: Pairing fails.

- A:** 1) Put the earbuds back to the charging case and make sure that they are off.
- 2) Take the earbuds out of the charging case and they will enter pairing mode automatically.
- 3) Choose "T16" in your phone to pair.

If the pairing still fails, check the following points:

- Make sure the earbuds and your Bluetooth device are next to each other or within 33 feet or 10 meters and there are no obstacles between.
- There are no signal interferences nearby (check the question "Connection is not stable" for signal interference conditions).
- Try to reboot your Bluetooth device.

Q2: I paired the earbuds with my phone before, but I failed to pair them with my phone again.

- A:** Turn on the Bluetooth of your phone and in "MY DEVICES", choose "T16" and tap "i" → "Forget This Device". Then pair the earbuds with your phone again.

Q3: Connection is not stable.

A: Make sure that the Bluetooth connection distance is within 33 feet or 10 meters and there is no object between the earbuds and your Bluetooth device, no radio or WIFI interference nearby.

Q4: Power runs out fast.

A: The earbuds playtime varies according to the volume level and audio content. Please put the earbuds back into the charging case to avoid unnecessary power consumption.

Q5: The earbuds which are being charged in the charging case reconnect to my phone.

A: When the charging case is out of power during charging, the earbuds will automatically turn on and reconnect to the last paired Bluetooth device. If the earbuds are not paired with the Bluetooth device, they will be automatically off after 5 minutes.

Specifications

Model	T16
Bluetooth Version	V5.0
Battery	30mAh (each earbud), 300mAh (charging case)
Charging Time	Approximately 1 hour (earbuds), 2 hours (charging case)
Input Rating	DC 5V $\overline{=}$ 1A
Music Playing/Call Time	4-5 hours per charge Up to 20 hours (with charging case)
Bluetooth Connection Distance	Up to 33 feet or 10 meters (No obstacle between)
Supporting Protocols	A2DP/HFP/HSP/AVRCP
Working Temperature	-10°C to 40°C

Safety and Warranty

Important safety instructions

- Use of earbuds will impair your ability to hear other sounds. Use caution while using your earbuds when you are engaging in any activity that requires your full attention.
- If you have a pacemaker or other electrical medical devices, you should consult your physician before using this product.
- This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy – never allow children to play with this product. Always store the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product

require replacement for any reason, including normal wear and tear or breakage, please contact us.

- Avoid exposing your product to rain, moisture or other liquids to protect against damage to the product or injury to you.
- Keep all products, cords, and cables away from operating machinery.
- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact us.
- Do NOT use in areas where there are explosive hazards.
- Do NOT submerge the earbuds in water. Do NOT expose the earbuds to moving water (e.g., from a faucet, etc.).
- Do NOT wear the earbuds while showering or bathing, or when participating in water sports, e.g., swimming, water skiing, surfing, etc.
- This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.

- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the earbuds.
- Dispose of the product according to local standards and regulations.

Note: *Always drive safely, avoid distractions and follow local laws!*

- Using the earbuds while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of the earbuds with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws.
- Use with caution while using your earbuds when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the earbuds from your ear or turning off your earbuds will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.
- When using and charging this product, basic precautions should always be followed, including the following:
 - ✘ Read all the instructions before using the charging case.

- ※ To reduce the risk of injury, close supervision is necessary when the charging case is used near children.
- ※ Do not expose charging case to water, rain, liquids or snow.
- ※ Use of a power supply or charger that is not recommended or sold by power pack manufacturer may result in a risk of fire or injury.
- ※ Do not use the charging case in excess of its output range.
- ※ Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- ※ Do not disassemble the charging case. Incorrect reassembly may result in risk of fire or injury.
- ※ Do not open, crush or expose a charging case to fire or excessive temperature. Exposure to fire or extreme temperature may cause explosion.
- ※ Have servicing performed by a qualified repair person using only identical replacement parts.

Warranty

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of defect.

We are happy to offer a one-year hassle-free warranty to all our products as we continue to make amazing products. Please contact us if you have any questions about our devices.