

VIOTEK®





GNV27DB

GAMING MONITOR

USER MANUAL



In order to continue serving our customers and providing the best products, our product information including our user manuals may receive updates from time to time. Please check our website for the latest user manuals and product materials.







Table of Contents

- Section 1: Safety Precautions 4**
- Section 2: Box Contents 5**
- Section 3: Product Overview 6**
 - 3.1 – Monitor Buttons 6
 - 3.2 – Monitor Ports 6
- Section 4: Stand Installation 7**
- Section 5: Mount Installation..... 8**
- Section 6: Basic Operation 9**
- Section 7: Indicator Light..... 9**
- Section 8: OSD..... 10**
 - 8.1 – OSD Menu Functions 11
- Section 9: ECO Modes and Gameplus..... 13**
- Section 10: Troubleshooting..... 13**
- Section 11: Specifications 15**
- Section 12: One-Year Limited Hardware Warranty 16**



Section 1: Safety Precautions


Read and observe the following warnings and information below.

1. Before cleaning, always unplug your monitor. It is recommended that you use dry cloth or lightly damp cloth to clean your monitor. Dry cloth is, however, the safest. If using damp cloth, wait for your monitor to completely dry before plugging it in again.
2. Do not use alcohol or ammonia-based cleaner and/or liquids to clean your monitor.
3. This monitor features ventilation openings on the back of the unit. Avoid blocking these openings to prevent the monitor from overheating.
4. Avoid placing this monitor near any heat sources, e.g., portable heaters or heating vents, as this may cause damage to your monitor.
5. Do not spray cleaner and or any kind of liquid directly onto the monitor's screen or any part of the monitor.
6. Do not insert anything into any part of the monitor especially the ventilation openings.
7. Always make sure your monitor is placed on a secure, level surface to prevent it from falling and sustaining damage.
8. Unplug your monitor during any extended periods of non-use.
9. Do not place heavy items on the monitor or monitor cables.
10. Do not attempt to disassemble or remove parts from the monitor. Any disassembly or modification etc. not performed by an authorized technician can result in damage to the monitor and/or possible exposure to high voltage electricity which may lead to serious injury or death.

VIOTEK® shall not be held responsible for injury or damage of products or persons due to failure to adhere to the aforementioned precautions or any others noted hereafter.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.




Section 2: Box Contents




Monitor x 1




Stand Stem x 1



Stand Base x 1



NO.1 Screws x 4
(for Stand Installation)



NO. 2 Screws x 4
(for Mounting)



DP Cable x 1




Power Cable x 1




Screwdriver x 1




User Manual x 1

 The screws come in different sizes: NO.1 (11mm x 4 pcs), NO.2 (35mm x 4 pcs). Extra screws may be included.




Section 3: Product Overview

3.1 – Monitor Buttons




- 1 M Menu Button:** Press to display the OSD menu or enter sub-menus.
- 2 ▼ Down Button:** Press to move down in the menus.
- 3 ▲ Up Button:** Press to move up in the menus.
- 4 E Exit Button:** Press to exit.
- 5 ⏻ Power Button:** Press to turn the monitor on/off.
- 6 LED Indicator:** Changes colors to indicate status. Refer to Section 7.


3.2 – Monitor Ports




- 7 Audio Output:** Insert one end of the audio cable into an external audio source, e.g., speakers or headphones, to pass audio signals through the monitor.
- 8 DP Connector:** Insert one end of the DP cable into the computer's DP output and connect the other end to the monitor's DP port.
- 9 HDMI Connectors:** Insert one end of the HDMI cable into the computer's HDMI output and connect the other end to the monitor's HDMI port.
- 10 Power Connector:** Insert the power cable to supply power to the monitor.




Section 4: Stand Installation

 Keep the foam underneath the monitor before attaching the stand.


1. Open the package and take out the monitor with foam still attached. Gently place it top-down on a desktop or table.
2. Take out the stem and base. Use the included screwdriver and one screw to fasten base to the stem.





3. Remove the foam covering the bottom of the monitor, then remove the adapter from the back of monitor. Use two NO. 1 screws to fasten adapter onto the stem.




4. With the stand fully assembled, reattach it onto the back of monitor. Then remove the remaining foam on monitor and stand it up on a flat, level desktop or table. Press the button to remove the monitor from the bracket if mounting.




 Make sure the monitor is laid on a flat surface before removing the stand.






Section 5: Mount Installation


1. Open the package and take out the product with foam still attached. Gently place it on a desktop or table. Remove the extra parts and the foam covering the monitor. If the monitor is already attached to the stand, remove the stand.




2. Press the button to remove the adapter on back of monitor, then tighten the included four NO. 2 screws onto the mounting holes on back of monitor.




3. Install the monitor on the wall, mount, or fixture as desired.





Section 6: Basic Operation

1. Insert one end of the DisplayPort (DP) cable into your PC's graphics card. An HDMI cable (not included) may also be used. A DP cable is included for your convenience.
2. Connect the other end of the cable to the corresponding connector on your monitor.




3. Connect the power cable to your monitor, then connect the other end to your power source. It is recommended that you use a surge protector with adequate voltage if a wall outlet cannot be reached directly.
4. Locate the power button on the monitor and press it to turn the monitor on.


AMD FreeSync

This feature is off by default. To activate, you must have a DP or HDMI cable, and FreeSync-compatible hardware with the latest graphic drivers installed. After connecting your computer and monitor with a DP or HDMI cable, you may receive a prompt to enable the feature on your computer. If you do not, you may need to enable the function in your graphics card menu. See your graphics card manufacturer's documentation for instructions.

Section 7: Indicator Light




Solid blue light indicates power is on and the monitor is operating normally. Flashing blue light indicates no video source, no horizontal or vertical signal has been detected or voltage is low. Please ensure your computer is on and all video cables are fully inserted and/or connected.



Section 8: OSD


The On-Screen Display (OSD) Menu may be used to adjust your monitor's settings and appears on screen after turning on the monitor and pressing the **M** (🏠) button.

 When using the monitor for the first time, settings will automatically adjust to optimal settings according to your computer's standard configuration settings.


1. Press any one of the buttons (**M**, **▼**, **▲**, **E**, **🔌**) to activate the navigation window.



2. Press **M** (🏠) to enter the OSD menu.




3. Press **▼** (🎮) or **▲** (🎮) to browse functions.
 - Highlight the desired function, then press **M** (🏠) to enter the sub-menu.
 - Press **▼** (🎮) or **▲** (🎮) to browse sub-menus, then press **M** (🏠) to highlight the desired function.
 - Press **▼** (🎮) or **▲** (🎮) to highlight an option, then press **M** (🏠) to confirm the settings and exit the current screen.
4. Press **E** (📄) to exit the current screen.




8.1 – OSD Menu Functions

Main Menu	Sub-Menu	Options	Description
Input Source	DP	NONE	Switch to DP signal input
	HDMI 1 (2.0), HDMI 2 (1.4), HDMI 3 (1.4)	NONE	Switch to HDMI signal input
	Brightness	0~100	Adjust display brightness
Brightness/ Contrast	Contrast	0~100	Adjust display contrast
	DCR	On	Turn on DCR function
Off		Turn off DCR function	
Color Setting	Gamma	Gamma 2.0	Set Gamma add-in
		Gamma 2.2	
		Gamma 2.4	
	Picture Mode	Standard, Text, Movie, Game, FPS, RTS	Set visual mode according to activity
	Color Temperature	Warm, Cool, User	Select color temperature
	Low Blue Light	0~100	Set blue light filtering level
	Hue	0~100	Adjust hue levels
	Saturation	0~100	Adjust saturation levels
Picture Quality Settings	Sharpness	0~100	Adjust display sharpness
	Response Time	Off, High, Middle, Low	Adjust response time
	Noise Reduction	Off, High, Middle, Low	Reduce the interference of image noise caused by signal source interference
	Super Resolution	Off, High, Middle, Low	When the resolution of the display screen is low, this function can be turned on to enhance the image resolution.
	Dynamic Luminous Control	On, Off	Compensate for gray scale display screen and strengthen the expression of gray scale
Display	Aspect Ratio	Wide Screen, 4:3, Auto	Select on-screen aspect ratio
	LedMode	Normal	Select DP version
Audio	Mute	On, Off	Turn mute mode on/off
	Volume	0-100	Adjust audio volume
	Audio Source	Auto Source, HDMI, DP	Select audio signal input via HDMI or DP



Main Menu	Sub-Menu	Options	Description
Multi-Window	Multi-Window	Off, PIP Mode, PBP 2Win	Select PIP/PBP modes according to the number of input signals etc.
	Sub Win2 Input	HDMI 1.4, HDMI 1.4, HDMI 2.0, DP	Select according to input signal for PIP/PBP mode
	PIP Size	Small, Medium, Large	Adjust the PIP/PBP display window size
	PIP Position	Top Right, Top Left, Bottom Right, Bottom Left	Adjust the PIP/PBP window position
	Swap	NONE	Swap the PIP/PBP signal sources
OSD	Language	English, Español, Русский, Français, 한국, 日本語, 简体中文	Set OSD language
	OSD H-Position	0-100	Adjust the OSD's horizontal position
	OSD V-Position	0-100	Adjust the OSD's vertical position
	OSD Transparency	0-100	Adjust OSD's overall transparency
	OSD Time Out	5-100	Set how long the OSD remains open after non-use
	OSD Rotation	Normal, 90, 180, 270	When the user flips the display, this function can also flip the OSD to achieve the best display angle
Other	DP Version	DP1.2	Select DP version
	FreeSync (Adaptive Sync)	On, Off	Turn on/off Freesync
	Reset		Reset monitor configurations



Section 9: ECO Modes and Gameplus


1. Press any one of the buttons (M, ▼, ▲, E, ⏻) to activate the navigation window.



2. Press ▼ (🎯) to switch Gameplus modes. Choose the crosshair icon best suited for your game. These game icons are primarily designed to optimize your aim during shooting games, though they can be used for other scenarios.



3. Press ▲ (📷) to switch ECO modes. These modes include Standard, Photo, Movie, Game, FPS, and RTS and can be used to optimize settings according to your activity. Standard mode is suitable for most activities.



4. Press E (📏) to switch color gamut mode between “Limited” and “Full” when optimal configuration is used (i.e., compatible graphics card and either DP or HDMI cables).



Section 10: Troubleshooting

The screen is blank


- Press the power button to turn on the monitor.
- Confirm the brightness and contrast settings are set normally.
- Check if the indicator light is flashing. If so, this indicates there is no signal from your video source.
- If your source is a notebook or laptop, be sure that its settings are in mirror or extension mode and the device itself is powered on.

The image is out of focus

- Ensure the video cable is inserted properly at both ends.

The screen is flashing

- Try an alternative power source. Insufficient power may be causing this issue.
- Ensure devices such as non-shielded speakers, fluorescent lighting, AC transformers, table fans, etc., are a safe distance away from your screen to avoid magnetic disturbances.



The color bleeds or visual effects appear unusual.

- If your screen is all red or blue, or any colors disappear, check to see that the cable is properly inserted. A loose connection can cause a bad signal.
- Try connecting to another video source for comparison.

The screen appears to be scrolling, rolling, or moving unusually.

- Check that your source frequency is within 144Hz.
- Reconnect and ensure your video cable is secure.

The monitor needs cleaning

- Make sure the monitor has been powered off before cleaning.
- Always use soft, non-abrasive cloth when cleaning.
- Use dry, non-abrasive cloth to gently remove debris or dust.
- If necessary, lightly dampen a non-abrasive cloth with water and gently clean the surface.
- Never use alcohol or ammonia-based cleaning solutions.
- Never spray liquid directly onto any part of the monitor.

The indicator light does not work

- Check that the power is on.
- Check that the power cable is connected and plugged in to a wall outlet.

Cannot plug and play.

- Ensure the monitor is compatible with PC.
- Ensure the graphics card is compatible with the monitor.
- Check cable connectors for curved or damaged pins. Replace cables if needed.

Dim image

- Adjust the brightness and contrast ratio.

Image jitter/moire pattern

- Nearby electric equipment may interfere with the monitor.

Light indicator is on or flashing, but there is no image displayed on screen

- Check that the monitor power is on.
- Check that the graphics card is installed properly.
- Check that the signal line connects securely with the monitor.
- Check cable connectors for curved or damaged pins. Replace cables if needed.

Color shortage (red, green, or blue)


- Inspect if the pins in the interface are curved.

Image position is not centered/the size is not right

- Please adjust Clock or Auto setting.


Color difference (colors are not optimized)

- Adjust RGB color or reset color temperature.



Section 11: Specifications

Item	Detail
Model Number	GNV27DB
Screen Size	27"
Curvature	1500R
Viewing Angle	178°(H) / 178°(V)
Aspect Ratio	16:9
Resolution	2560 x 1440p
Backlight	E-LED
LED Indicator	Power on: Blue (solid); Power saving: Blue (flashing)
Typical Brightness	250 cd/m ²
Default Color Temp.	6500
Color Gamut	96% sRGB; 85% NTSC; DCI-P3 90%; Adobe RGB 83%
Contrast Ratio	3000:1 (Static)
Dot Pitch	0.2331 x 0.2331 mm
Response Time	6ms (GTG)
Refresh Rate	144Hz
Ports	HDMI 2.0 x 1, HDMI 1.4 x 2, DP x 1, Audio out x 1
Power	DC 12V, Min 4A
Power Consumption	Typical: 37W, Max: 58W; Standby <=0.5W
OSD Language	English, Español, Русский, Français, 한국, 日本語, 简体中文
Usage Temp.	32°F~95°F (operating), -4°F~140°F (storage), 10-90% RH (non-condensing)
Tilt Angle	Forward 5°± 2°; Backward 15°± 2°
VESA Mounting	75 x 75 mm
Dimension (With Stand)	24.26 x 17.84 x 7.7 in (616.2 x 453.1 x 195.7mm)
Weight	10.69 lb. / 14.82 lb. (incl. packaging)



Section 12: Three-Year Limited Hardware Warranty

Your VIOTEK® GNV27DB Curved Monitor ("Product") includes a Three-Year Limited Hardware Warranty ("Warranty"). The Warranty covers product defects in materials and workmanship under normal use. This Warranty is limited to residents of the United States and Canada only and is available only to original purchasers. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

This Warranty starts on the date of your purchase and lasts for three years (the "Warranty Period"). The Warranty Period is not extended if the Product is repaired or replaced. We may change the availability of this limited warranty at our discretion, but any changes will not be retroactive.


Warranty services are provided by Warranty Pro ("WP"). If a hardware defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, WP will: (1) repair the hardware defect by using new or refurbished parts that are equivalent to new in performance and reliability; or (2) exchange the Product with a new product or a refurbished one that is substantially equivalent to the original product. This Warranty is for one replacement only of like-items and does not cover items out of production if the product is no longer made or stocked. This Warranty is not assignable or transferable. The original purchaser may call WP's toll-free number at 1-855-229-9472 for service request.

When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes WP's property. This warranty only covers technical hardware defectiveness during the warranty period and under normal use conditions. WP does not warrant uninterrupted or error-free operation of this Product. This Warranty does not cover any damage due to: (a) transportation; (b) storage; (c) improper use; (d) failure to follow the product instructions or to perform any preventive maintenance; (e) modifications; (f) unauthorized repair; (g) normal wear and tear; or (h) external causes such as accidents, abuse, or other actions or events beyond our reasonable control.

Important: Do not disassemble the Product. Disassembling the Product will void this Warranty. Only WP or a party expressly authorized by WP should perform service on this Product.

DISCLAIMER OF WARRANTY: THE REMEDIES DESCRIBED ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES AND OUR ENTIRE LIABILITY FOR ANY BREACH OF THIS LIMITED WARRANTY. OUR LIABILITY SHALL UNDER NO CIRCUMSTANCES EXCEED THE ACTUAL AMOUNT PAID BY YOU FOR THE DEFECTIVE PRODUCT, NOR SHALL WE UNDER ANY CIRCUMSTANCES BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR PUNITIVE DAMAGES OR LOSSES, WHETHER DIRECT OR INDIRECT.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.



THE DURATION AND REMEDIES OF ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY.

DECLARATION OF CONFORMITY

This device complies with Part 15 of the FCC Rules.


Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RELATED INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.



VIOTEK[®]

COPYRIGHT © 2020 VIOTEK. ALL RIGHTS RESERVED.

