

getting started

Congratulations!

You now own one of the most advanced personal audio/visual stimulation devices available.

We realise you are eager to get started and always recommend that you read the full Kasina manual if you have the time, which lists all the advanced functionality.

At the very least, please read the product standard and safety statements before continuing.

The MindPlace User Forum is a great place for answers to questions and for sharing experiences as well as having the latest version of manuals, tutorials, guides, downloads and help with creating Kasina sessions and can be found on the MindPlace support site at:

<http://mindplacesupport.com/forum/>

Thank you from all here at MindPlace, we hope you enjoy using your Kasina!

Quickstart instructions

1. Charge the Kasina with the included mini-USB power adaptor, this should take several hours or less.
2. Insert the micro-SD card as shown. You will feel a slight spring pressure before it locks into place.
To remove card Ensure your Kasina is turned off then gently press the micro-SD card so that it unlatches and springs out sufficiently to grasp.
3. Connect GanzFrames.
4. Connect supplied Earbuds or your own Headphones.
5. Press and hold the Power button for 2 seconds to turn Kasina on.
6. Navigate using the Control Pad to "Sessions" icon and push the Select button.
7. Navigate folders and sessions that you wish to play using Control Pad Up, Down and Select.
8. Push Control Pad Select button to start playing the session.
9. Adjust Earbud/Headphone volume and GanzFrames brightness level to suit.

kasina quickstart

