



# NEPHELE

ELECTRIC BIKE

USER MANUAL





# Contents

Don't Ride Until You Read This .....	02
Warning Message .....	03
Unpacking and Product Specs .....	07
Get to Know Your E-Bike .....	08
Install Front Mudguard, Front Light .....	09
Front Wheel Installation .....	10
Handlebar Installation .....	12
Folding the Bicycle Frame .....	14
Pedal Installation and Folding .....	15
Saddle Installation/Adjustment .....	16
Battery Removal .....	18
Startup Precautions .....	19
Charge Your E-Bike .....	20
Charge Your E-Bike: Method 2 .....	21
Function Instructions .....	22
Tire Inflation Instructions .....	23
Maintenance & Repair .....	25
Basic Operations/Modes .....	28
Battery Information .....	29
Warranty .....	31



## Congratulations on your purchase!

This user manual will help you assemble and operate your new electric bike. Be sure to read **ALL OF THE INFORMATION** in this manual before riding.

**NOTE TO ALL RIDERS UNDER 18 YEARS OF AGE:** It's very important that you get parental permission before riding your electric bicycle.

**TOOLS INCLUDED:** 4mm、 5mm Allen wrench, 13mm&15mm open-end wrench\*2, Flat Head & Phillips dual-purpose Screwdriver.





# Don't Ride Until You Read This



**ALWAYS** wear a helmet when riding your electric bike.



Make sure your electric bike has a **full battery** before taking it out to ride.



**Always** be aware of local road laws, and follow them.



**Do not** ride the bike under the influence of drugs or alcohol.



**Always** respect pedestrians.



**Do not** ride under wet conditions. The electric bike may slide from under your feet causing injury. Wet conditions may damage the electronics and void the warranty.



**To conserve electricity**, use assist mode and avoid zero starting, frequent braking, driving against the wind, carrying heavy loads including other people and riding with insufficient air pressure.




WARNING: Lithium-ion Batteries and/or products that contain Lithium-ion Batteries can expose you to chemicals including cobalt lithium nickel oxide, and nickel, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)




## Warning Message

1. **Avoid water** -The electric bike is not waterproof. The electronics may be damaged due to water and water damage is not covered by our warranty. Riding in wet conditions is also very dangerous and may result in injury.
2. **Avoid prolonged exposure** to sun or rain and avoid storage in places with high temperatures or corrosive gas.
3. **Whenever you ride**, you risk severe injury or even death from loss of control, collisions, and falls. Use caution and ride at your own risk.
4. **Do not modify** the product from the manufacturers original design.
5. **Do not exceed** the posted speed limit and obey all traffic laws.
6. **Avoid touching** the charging port directly and do not let it make contact with a metal object.
7. **Keep hands and all body parts away** from moving parts while operating the electric bike.
8. **Before riding** - be sure to check the electric bike over and make sure all components and function are operating correctly before each use.
9. **Before riding** - be sure to check that the braking system is functioning properly; also be sure to check that all safety labels are in place and you understand the safety warnings.
10. **Before riding** - be sure that any and all axle guards, chain guards, or other covers or guards supplied by the manufacturer are in place and in serviceable condition.
11. **Before riding** - be sure to check that the tires are in good condition, inflated properly, and have sufficient tread remaining.
12. **Never exceed** the 264lbs (120 kg) maximum load rating.
13. **The electric bike should never** be used by children under the age of 16.
14. **Maximum Speed** -Your electric bike accelerates to a maximum speed of 15.5 mph.

15. **Make note that additional insurance may be required** to cover situations you encounter while riding an electric bike. It is recommended that you contact an insurance company or broker for advice and consultation.
16. **To conserve electricity**, use assist mode and avoid zero starting, frequent braking, driving against the wind, carrying heavy loads including other people and riding with insufficient air pressure.





**Correct**  
Forehead covered

**Incorrect**  
Forehead exposed

**! ALWAYS WEAR A HELMET IT COULD SAVE YOUR LIFE!**

A properly fitting, CPSC approved, bicycle helmet should be worn at all times when riding your bicycle. In addition, if you are carrying a passenger (only use an approved child safety seat), and remember, the passenger must also be wearing a helmet.

The correct helmet should:

- be comfortable
- be lightweight
- have good ventilation
- fit correctly
- cover the forehead
- be securely fastened on the rider.

**FCC REGULATIONS** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

following measures:

- \*Reorient or relocate the receiving antenna.

- \*Increase the separation between the equipment and receiver.

- \*Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- \*Consult the dealer or an experienced radio/TV technician for help.



# Unpacking and Product Specs

Remove all packaging material, then inspect each item for any accidental damage that may have occurred during shipping. You should find each of these items in your box:

1



**ELECTRIC BIKE**

2



**BATTERY CHARGER**

3



**TOOLS: (2)LARGE WRENCH,  
(2)ALLEN WRENCHES,  
(1)SCREWDRIVER  
(2)FOOTREST  
(1)FRONT AXLE**

ITEM	SPECIFICATIONS
Model	NEPHELE
Unfolded Dimensions	1470*545*1140mm(57.9*21.5*44.9 in)
Folded Dimensions	510*690*800mm(20.1*27.1*31.5 in)
Package Dimensions	1240*220*630mm(48.1*8.7*24.8 in)
Max Load	264 lbs (120 kg)
Max Speed	15.5mph
Battery	36V 7.8Ah Output 42V 1.5A DC 5.5*2.1mm
Battery Specifications	Input 110-240V 50/60Hz AC Plug;
Max Angle of Climb	14 degrees
Charging Time	5.5hours
Tire Pressure	40 PSI
Seat	Adjustable
IP Level	IPx4



# Get To Know Your E-Bike




# ✂ Install Front Mudguard, Front Light



Prepare the front mudguard.



Secure the front mudguard and headlights to the frame (screws are already installed on the frame, simply remove the screws to install)



Secure the front mudguard bracket to the frame (screws are already installed on the frame, remove the screws to install).

# 🔧 Front Wheel Installation




Remove the brake caliper protector.




Locate the front wheel axle core.



Remove one nut and washer from one side, then insert the axle core into the front wheel.



Slowly insert the front wheel into the front fork, and install the brake pads into the brake caliper. Pay attention to the placement of the washers; the washer positions are as shown in the diagram.



Pay attention to the installation position of the washers, as shown in the diagram.




Use a 15mm open-end wrench to tighten both nuts on both sides. Please note: the washers should be positioned as shown in the diagram, and the anti-rotation hook washer must be installed in the specified location on the front fork.

# Handlebar Installation



Open the stem quick-release clamp.





Insert the valve stem and handlebars. (Note: this step can only be done when the stem is folded down).



Then, tighten the stem quick-release clamp. (Note: this step can only be done when the stem is folded down).



Note: Insert the minimum safety line completely into the handlebar stem.



Lift the stem upward, place the folding bolt into the stem locking groove, and then press down on the folding handle to secure it. (Note: Before riding, ensure that the folding mechanism is securely locked in place).

# ✂ Folding the Bicycle Frame



Open the folding handle.



Pull out the folding locking bolt.



Pull the folding locking bolt upwards.



While pulling the folding locking bolt, fold the front and rear wheels together (adjust the crank so that it does not interfere with the folding angle).

# ✂ Pedal Installation and Folding



Prepare the pedal and wrench, and distinguish the left and right pedal according to 'L' and 'R'. 'R' represents the right side, and turn clockwise to lock the right pedal. 'L' represents the left side, and turn counterclockwise to lock the left pedal. The pedal can be folded by pressing inward and lifting up.



# Saddle Installation/Adjustment



Open the seatpost quick-release lever.



Insert the seatpost into the desired comfortable riding height. If it's tight, you can rotate the seatpost while pushing it downward.



Rotate the saddle to the comfortable riding angle, and tighten the seatpost quick-release clamp.



Push up the seat folding handle to flip the folding seat.



Use a 15mm open-end wrench to loosen the screw for adjusting the saddle's forward and backward height and angle. Adjust it to the desired angle and then tighten the screw.



Note: The minimum safety insertion line must be inserted into the seatpost.

# Battery Removal



Flip the seat forward to fold it, unplug the power output connector, rotate the battery lock key to the unlock position, and lift the battery upward to remove it.

## Startup Precautions



When you receive the bicycle, the power output cable is disconnected, and the battery output switch is turned off. You need to insert the power output cable and rotate the key to open the power output before you can power it on and use it.


# Charge Your E-Bike

You can also charge your battery installed in the bike using the exterior charging port.



1. Locate the charging port
2. Plug one side of the charger into the charging port and plug the other into an outlet.
3. A red light indicates the battery is charging, green indicates the battery is full.
4. Charging Time: 5.5 hours.

## ✂ Charge Your E-Bike: Method 2



Remove the battery, plug one end of the charger into the battery and the other end into the power supply. Red light shows the battery is charging and the green light means the battery indicates a full charge.

# Function Instructions



To ring the bells, push your fingers downward.



Turn the key to the right one notch to power on. The instrument panel will illuminate. Turn it right again to turn on the headlights and tail lights (the tail lights will flash when braking). Reverse the rotation to turn them off.



When the battery is fully charged, it will display 4 bars of charge. When there is only one bar remaining or it is blinking, it indicates low battery and requires timely charging.



When starting the throttle, press the brake once to release the P (Parking) mode before turning the throttle to start the motor.



# Tire Inflation Instructions

## Tires and Tubes

After assembling your bike, it will be necessary to inflate the tires. Check the sidewall of the tire for the correct tire pressure (PSI) and inflate tires accordingly with a **MANUAL BICYCLE PUMP**. **Improper inflation is the biggest cause of tire failure. Due to the slightly porous nature of bicycle inner tubes, it is normal for your bike tires to lose pressure over time. For this reason it is critically important to maintain the proper tire inflation on your bike.**

1. Your bicycle has been equipped with tires which the bike's manufacturer felt were the best balance of performance and value for the use for which the bike was intended. The tire size and pressure rating are marked on the sidewall of the tire. **CAUTION:** Pencil type automotive tire gauges and gas station air hose pressure settings can be inaccurate and should not be relied upon for consistent, accurate pressure readings. Instead, use a high quality dial gauge.




**WARNING: NEVER INFLATE A TIRE BEYOND THE MAXIMUM PRESSURE MARKED ON THE TIRE'S SIDEWALL. EXCEEDING THE RECOMMENDED MAXIMUM PRESSURE MAY BLOW THE TIRE OFF THE RIM, WHICH COULD CAUSE DAMAGE TO THE BIKE AND INJURY TO THE RIDER AND OTHERS. THE BEST WAY TO INFLATE A BICYCLE TIRE TO THE CORRECT PRESSURE IS WITH A BICYCLE PUMP. NEVER USE A SERVICE STATION AIR HOSE TO INFLATE A BICYCLE TIRE. IT IS DESIGNED FOR LARGER TIRES AND IT CAN EXCEED THE RECOMMENDED MAXIMUM PRESSURE AND IT MAY BLOW THE TIRE OFF THE RIM.**


Tire pressure is given either as maximum pressure or as a pressure range. How a tire performs under different terrain or weather conditions depends largely on tire pressure. Inflating the tire to near its maximum recommended pressure gives the lowest rolling resistance; but also produces the harshest ride. High pressures work best on smooth, dry pavement. Very low pressure, at the bottom of the recommended pressure range, gives the best performance on smooth, slick terrain such as hard-packed clay, and on deep, loose surfaces such as deep, dry sand. Tire pressure that is too low for your weight and the riding conditions can cause a puncture of the tube by allowing the tire to deform sufficiently to pinch the inner tube between the rim and the riding surface.

Some special high-performance tires have unidirectional treads: their tread pattern is designed to work better in one direction than in the other. The sidewall marking of a unidirectional tire will have an arrow showing the correct rotation direction. If your bike has unidirectional tires, be sure that they are mounted to rotate in the correct direction.

2. The tire valve allows air to enter the tire's inner tube under pressure, but doesn't let it back out unless you want it to. There are primarily two kinds of bicycle tube valves: The Schraeder Valve and the Presta Valve. The bicycle pump you use must have the fitting appropriate to the valve stems on your bicycle. The Schraeder is like the valve on a car tire, this is the type of valve stem you should have on your bike. To inflate a Schraeder valve tube, remove the valve cap and push the air hose on you bike. To inflate a Presta valve tube, remove the valve cap and push the air hose or pump fitting onto the end of the valve stem. To let air out of a Schraeder valve, depress the pin on the end of the valve stem with the end of a key or other appropriate object.



Schraeder Valve



Presta Valve



# Maintenance & Repair

**Correct routine maintenance of your new bike will ensure a longer life for your bike and a safer ride for you.**

Every time you ride your bike, its condition changes. The more you ride, the more frequently maintenance will be required. We recommend you spend a little time on regular maintenance tasks. The following schedules will assist you in knowing what tasks need to be performed and how often. **If you have any doubts about your abilities to accomplish these tasks, we recommend you take your bike to a professional bicycle mechanic periodically to have them done.**

## Schedule1 - Lubrication

Frequency	Component	Lubricant	How to Lubricate
Weekly	chain derailleur wheels derailleurs brake calipers brake levers	chain lube or light oil chain lube or light oil oil oil oil	brush on or squirt brush on or squirt oil can 3 drops from oil can 2 drops from oil can
Monthly	shift levers	lithium based grease	disassemble
Every Six Months	shift levers brake cables	oil lithium based grease	2 drops from oil can disassemble
Yearly	bottom bracket pedals derailleur cables wheel bearings headset seat pillar	lithium based grease lithium based grease lithium based grease lithium based grease lithium based grease lithium based grease	bicycle mechanic disassemble disassemble bicycle mechanic bicycle mechanic disassemble

**Note: The frequency of maintenance should increase with use in wet or dusty conditions. Do not over lubricate-remove excess lubricant to prevent dirt build up. Never use a degreaser to lubricate your chain (WD-40™)**

## **Schedule2 - Service Checklist**

**NOTE: Many instructions for adjustments can be found in the assembly portion of this manual.**

<b>Frequency</b>	<b>Task</b>
Before every ride	check wheel and pedal tightness check tire pressure check brake operation check wheels for loose spokes, loose axle nuts or quick release make sure all fasteners are tightened securely
After every ride	quick wipe down with damp cloth
Weekly	lubrication as per schedule 1
Monthly	lubrication as per schedule 1 check derailleur adjustment check brake adjustment check brake and gear cable adjustment check tire wear and pressure check wheels are true and spokes tight check hub, head set and crank bearings for looseness check pedals are tight check handlebars are tight check seat and seat post are tight and comfortably adjusted check frame and fork for trueness

	check all nuts and bolts are tight
Every six months	lubrication as per schedule 1 check all points as per monthly service check and replace brake pads, if required check chain for excess paly or wear
Yearly	lubrication as per schedule 1

**NOTE: OWNERS ARE RESPONSIBLE FOR ALL MAINTENANCE AND SERVICE OF THE BICYCLE. FAILURE TO DO SO MAY VOID YOUR WARRANTY, CAUSE DAMAGE TO YOUR BIKE OR ITS COMPONENTS, AND MAY CAUSE AN ACCIDENT.**



# Basic Operations/Modes

1. **Power Assist:** Turn the key to power the bike. The motor will automatically engage when you start pedaling and disengage when you stop.

2. **Throttle Assist:** Turn the key to power the bike. Press the brake lever once to release the P (Parking) mode. Twist the right grip to engage the throttle. The motor will power the bike until you release the grip.

3. **Unassisted Riding:** Without powering the bike, you may still ride the bike like a traditional non-electric bicycle.



# Battery Information

Before using the charger locate the voltage selector switch (li-ion chargers only) on the back of the charger. Select either 115 volts or 230 volts depending on your country of residence. Using the wrong voltage setting will permanently damage the charger and/or electrical components on the hybrid electric bicycle.

## **BATTERY ASSEMBLY**

1. Use the matching charger.
2. Insert the round plug into the E-Bike first and then insert the charger plug into the electrical socket.
3. A red light indicates the battery is charging.
4. A green light indicates the battery is fully charged.
5. The Key lock position will vary from model to model.
6. The battery is removable, the battery can be charged attached to the E-Bike or pulled out and charged separately.

## **CHARGING THE BATTERY**

1. When using the charger for the first time, carefully check whether the rated output voltage of the charger is consistent with the battery voltage and check whether the charger input voltage is consistent with the grid voltage.
2. When charging, first put the charger in a ventilated place, then insert the charger output plug into the charging port. Plug the electrical power plug into the 100-240V 50/60Hz AC Power Supply. Be sure to keep the input plug in contact with the AC outlet.
3. After charging, the input plug of the charger shall be pulled out first, and then the output plug connected with E-Bike shall be pulled out. Do not leave the charge plugged in.

## **PRECAUTIONS FOR BATTERY PROTECTION**

1. Do not place anything on the battery and charger when charging, otherwise the charger may overheat and cause serious damage.
2. Only use the charger supplied by the original factory to charge the battery, if you use a different charger your battery will be disqualified from warranty.
3. You can charge your battery at any time if the battery loses power.
4. If you do not use or charge your battery for an extended period of time, battery performance will decrease. If you do not plan to ride your bike for an extended period of time it is recommended to plug in and charge the battery Insert Care/Maintenance section an extended period every 4-6 weeks.
5. Protection can make your battery maintain about 80% of its capacity after more than 500 cycles. But overall decline is inevitable.
6. If the battery remains in a status not charged a long time, it will lead to permanent loss of performance.
7. If you want to store your battery for an extended period, please store and discharge it in a cool and dry place.
8. Keep the temperature between 50-70°F and avoid direct sunlight. Take the battery out for charging every 30 days.
9. Do not intentionally short-circuit the battery which will cause very serious damage and void the warranty.
10. Dispose of your batteries responsibly. Research local recycling regulations.
11. If you have questions about battery use, maintenance, or storage, please contact customer service.
12. Only use the battery supplied with this electronic bike.
13. Never charge a lithium battery unsupervised.

# Warranty

Please contact our customer service team if you are experiencing problems or need more detailed information.

US team after-sales email: **support.us@hoverflys.com**

CA team after-sales email: **support.ca@hoverflys.com**

1. Users should operate in accordance with the product manual. In case of any performance fault caused by production quality, the company shall perform the obligations of the three guarantees in accordance with the provisions of relevant laws and regulations of the state.
2. The company is still responsible for the after-sales service of the faults beyond three guarantees and the major components in the three guarantees, but there will be a cost for repair.
3. If the battery replacement is over the warranty time, our company will supply the battery at factory price. To ensure safety, and avoid pollution.
4. We do not cover physical damage due to negligent care and extreme riding.



(US)WWW.HOVERFLYS.COM





# **(US)BAIKE INC**

2533 ROYAL LN DALLAS, TX 75229