USER MANUAL

OKHAHA Wireless Controller 2 Pack, Compatible with PS3 | Blue + Red | ASIN B09P2LWCNV

Product overview

This package contains two OKHAHA wireless controllers compatible with PlayStation 3 (PS3) consoles. The controllers support wireless gameplay, rechargeable operation, vibration feedback, and motion-sensor input in compatible PS3 games.

Package contents

- 1 blue wireless controller
- 1 red wireless controller
- 2 USB charging/data cables
- User instructions

Compatibility

- Compatible with PlayStation 3 consoles and PS3 games that support standard controllers.
- These controllers are OKHAHA products. They are not Sony products and are not affiliated with or endorsed by Sony Interactive Entertainment Inc.
- Compatibility with other consoles, systems, or platforms is not claimed.
- Vibration and motion-sensor functions depend on game support and game settings.

Initial connection and pairing

1. Turn on the PS3 console.
2. Connect one controller to the console with the supplied USB cable.
3. Press the PS button. The player indicator will show the assigned controller number.
4. Disconnect the cable after pairing. The controller should continue to operate wirelessly.
5. Repeat the same steps for the second controller. Pair and test one controller at a time during initial setup.

Important: The first connection to a PS3 console must be completed by cable. A controller may need to be paired again after it has been used with another console or after a reset.

Charging

- Use the supplied USB cable and connect the controller to a powered PS3 USB port or a standard 5 V USB power source.
- Confirm that the cable is fully seated and that the charging indicator responds.
- Do not use a damaged cable or force the connector into the charging port.
- If charging does not start, test the supplied cable on another PS3 USB port and reset the controller before trying again.

Normal operation

- Use the D-pad, face buttons, shoulder buttons, triggers, START, SELECT, analog sticks, and PS button as required by the game.
- Use the PS3 system menu to turn off a controller when it is no longer in use.
- If a controller remains unresponsive after the console is turned off, press the rear reset button briefly, then pair it again by cable.

Troubleshooting

Issue	Recommended action
Controller will not connect	Connect it directly to the powered PS3 with the supplied cable, press the PS button, then disconnect the cable after the player number is assigned. If necessary, press the rear reset button briefly and repeat the pairing steps.
Wireless connection drops or input lags	Charge the controller, move closer to the console, remove nearby wireless interference, restart the console, and pair the controller again. Test the second controller separately to isolate the cause.
Controller will not charge	Check that the cable is fully inserted, try another PS3 USB port, and inspect the port and cable for damage. Avoid fast-charging-only adapters that may not provide standard 5 V USB output.
Button is slow, stuck, or unresponsive	Turn off the controller, check for debris around the button, press the button several times without excessive force, reset the controller, and test it in the PS3 system menu or another game.
Analog stick does not respond correctly	Restart the game, move the stick through its full range, reset and reconnect the controller, and test it in another game. Do not press or twist the stick while powering on or pairing.
Vibration or motion sensing does not work	Confirm that the game supports the function and that vibration or motion control is enabled in the game settings.
Controller turns on unexpectedly or remains on	Use the PS3 menu to turn off the controller. If it does not respond normally, press the rear reset button briefly and pair it again before use.

Care and safety

- Keep the controllers and cables dry. Do not expose them to excessive heat, impact, or prolonged direct sunlight.
- Do not disassemble, crush, puncture, or attempt to replace the internal rechargeable battery.
- Stop using a controller if the housing, cable, charging port, or battery shows visible damage, swelling, unusual odor, or excessive heat.
- Keep the product and small parts away from young children.

Support information

When requesting support, provide the Amazon order number, ASIN B09P2LWCNV, controller color, and a brief description of the issue and troubleshooting already completed.