



Tenir le verrou de façon à incliner la boule vers le haut. Avec la clé fournie déverrouiller la serrure pour déclencher le mécanisme, pour être capable de découpler la boule du casting. Assurez vous que le mécanisme reste ouvert et enlever la clé de la serrure.



Une fois les 2 partie découpler, entrer la partie boule dans votre main de remorque de façon à avoir le dégagement vers l'avant de la remorque pour ensuite accoupler le casting avec la boule en s'assurant que la lèvre de la main soit dans le casting.



Pour verrouiller en place, pousser fermement le mécanisme pour verrouiller le verrou en place.

Pour désinstaller, Assurez vous que la clenche est bien fermée. Maintenir le casting, déverrouiller la serrure et tirer sur le mécanisme vers le bas, ensuite enlever votre casting de la main de remorque. Maintenir la boule et ouvrir votre clenche pour déloger la boule de la main de remorque. Pour ne pas perdre une des 2 parties réassembler les 2 partie ensemble.

Entretien minimum du verrou

Lubrifier avec un lubrifiant** utilisé par les serruriers dans la serrure et autour du mécanisme trimestriellement.

***Ne pas utiliser de lubrifiant en aérosol ou tout autre produit à base de silicone.*



Hold lock in order to have ball facing upwards. Using the supplied key, open the lock in order to activate the mechanism to uncouple the ball from the casting. Ensure that the mechanism remains open and remove the key from the lock.



Once both parts are uncoupled, insert the ball in your trailer coupler to have clearance facing the front of the trailer, then couple the casting with the ball, ensuring that the lip of the trailer coupler is inserted in the casting.



In order to lock into place, push firmly onto the mechanism.

To uninstall, ensure that the lock is completely closed. While keeping the casting in place, unlock and pull mechanism downwards, then remove the casting from the trailer coupler. Hold the ball and open the lock to dislodge the ball from the trailer coupler. To prevent losing parts, reassemble the lock and the ball

Minimal Lock Maintenance

Quarterly, lubricate inside the lock and around the mechanism with a lubricant used by locksmiths.

***Do not use any spray lubricant or any other silicon-based product.*