Please Read and Save this Use and Care Manual
Por Favor Lea y Guarde este Instructivo Antes de Usar el Producto

imusa®



LOOK FOR IMUSAUSA ON:
SÍGUENOS EN IMUSAUSA:

IMPORTANT SAFETY, USE & CARE INFORMATION Please read this information before you use your cookware. These instructions are for your general safety, use and care to avoid personal injury and damage to your cookware or property. Please note that some sections may not apply to your specific line of cookware.

CARE & CLEANING Standard Care: • Before first use and after each use, wash cool pans thoroughly with mild dishwashing detergent and warm water. • Dry thoroughly with soft cloth and let pots sit in open air before storing. Spots and Stains: • Do not use oven cleaners to clean cookware. • Remove burnt-on foods by soaking for a few minutes. • Do not use steel wool, coarse scouring pads or powder. Dishwasher: • This cookware is not dishwasher safe. Storage: • To avoid scratches or chips on the cookware exterior, place paper towels between pans when storing. • Don't drop or bang cookware against hard surfaces, as enamel may chip.

FIRST USE

- Remove all packing material and stickers from the product and save instruction manual.

NEED HELP?

For service, repairs, or any questions regarding your appliance, call the number on the last page of this manual. Please **DO NOT** return the product to the place of purchase. Also, please **DO NOT** mail product back to manufacturer. You may also want to consult the website listed on the last page of this manual.

Service, Replacement & Parts Information

If you have questions regarding the operation of your IMUSA appliance or need replacement parts, contact us by any of these methods:

Write us or Call us using the contact information above
Inquires will be answered promptly by telephone, email, or letter. When writing, please include a phone number.

When contacting the Customer Service department, please specify the model number, place & date of purchase, and provide a copy of the receipt for product.

Manufactures Limited Warranty

COOKWARE & GADGETS: 90-Day Limited Warranty

What does it cover?

- Manufacturer defects in materials or workmanship (returns will only be accepted if due to a manufacturer defect and will not be accepted after 90 days from date of purchase. Returns will only be accepted with original receipt)
- Applies only to IMUSA cookware products and kitchen gadgets purchased and used in the United States, Hawaii or Alaska

How do you get service?

- Save your receipt as proof of date of purchase
- Email customerserviceimusa@groupeseb.com, or call 1-800-850-2501
- If you need parts or accessories, please contact us via email or phone

Warranty does NOT cover:

- Damage from commercial use
- Damage from misuse, abuse, or neglect
- Products that have been modified in any way
- Damage due to accidents or repairs

SMALL KITCHEN APPLIANCES & PRESSURE COOKERS: One Year Limited Warranty

What does it cover?

- Manufacturer defects in materials or workmanship (returns will only be accepted if due to a manufacturer defect and will not be accepted after 1 year from date of purchase. Returns will only be accepted with original receipt)

- Applies only to IMUSA small kitchen appliances and stove-top pressure cookers purchased and used in the United States, Hawaii or Alaska

How do you get service?

- Save your receipt as proof of date of purchase
- Email customerserviceimusa@groupeseb.com, or call 1-800-850-2501
- If you need parts or accessories, please contact us via email or phone

Warranty does NOT cover:

- Damage from commercial use
- Damage from misuse, abuse, or neglect
- Products that have been modified in any way
- Other accessory items that are packed with the unit
- Damage due to accidents or repairs

INSTRUCTION MANUAL

If you have any questions, please contact us at:
Para mayor información puede contactarnos a:

IMUSA USA, LLC
6000 NW 97TH AVENUE, UNIT 26
Doral, FL 33178
1-800-850-2501
customerserviceimusa@groupeseb.com
www.imusausa.com

MADE IN CHINA /

imusa®