User Manual of Product 1:


OXO Good Grips V-Blade Mandoline Slicer, White


User Manual of Product 2:

OXO Good Grips Large Salad Spinner - 6.22 Qt., White

Use & Care

GOOD GRIPS V-BLADE MANDOLINE






CAUTION!
The OXO GOOD GRIPS V-Blade Mandoline Slicer blades are very sharp. Handle them with care when using the Mandoline and when cleaning the components. Always use the Food Holder to prevent injury. Do not leave the OXO V-Blade Mandoline Slicer or any components within reach of children.


Use & Care

GOOD GRIPS V-BLADE MANDOLINE


STRAIGHT OR CRINKLE CUTTING




1. Straight or crinkle cutting requires slicing insert (**D**) and either the straight V-Blade (**E**) or the crinkle V-Blade (**F**). (For details on switching blades, see pg. 3)



2. Load slicing insert (**D**) and either the straight V-Blade (**E**) or crinkle V-Blade (**F**) into mandoline. Load food into food holder (**I**).




3. Push button on dail and turn to select desired slice thickness.




4. Using food holder (**I**), run food over blade to make slices.


JULIENNING OR FRENCH FRYING




1. Julienning requires straight V-Blade (**E**)and either the julienning blade (**G**) or French fry blade (**H**). (For details switching blades, see pg. 3 and 4)



2. Load straight V-Blade (**E**) and either the julienning blade (**G**) or French fry blade (**H**) into mandoline. Load food into food holder (**I**).



3. Push button on dial and turn to select the required slice thickness (blade is color coded).




4. Using food holder (**I**), run food over blades to make julienne slices. Lift on back stroke.


Use & Care

GOOD GRIPS V-BLADE MANDOLINE


SWITCHING V-BLADES




1. Push tabs of straight V-Blade (**E**) until it releases.




2. Remove straight V-Blade (**E**).




3. Push button on dial and turn to unlock position. Open bottom runway (**B**).




4. Pinch tabs of crinkle V-Blade (**F**) in storage until it releases.




5. Remove crinkle V-Blade (**F**) from storage.



6. Place straight V-Blade (**E**) in storage.



7. Close bottom runway (**B**).




8. Insert crinkle V-Blade (**F**).


Use & Care

GOOD GRIPS V-BLADE MANDOLINE


SWITCHING JULIENNE BLADES




1. Push button on dial and turn to unlock position. Open bottom runway (**B**).




2. Remove slicing insert (**D**).




3. Open top runway (**C**).




4. Select desired julienne blade (**G**) or (**H**) from under deck storage.



5. Close top runway (**C**).



6. Insert desired julienne blade (**G**) or (**H**).




7. Close bottom runway (**B**).


Use & Care

GOOD GRIPS V-BLADE MANDOLINE


DISASSEMBLY & CLEANING




1. Push tabs of straight V-Blade (**E**) until it releases.




2. Remove straight V-Blade (**E**).




3. Push button on dial and turn to unlock position. Open bottom runway (**B**).




4. Pinch tabs of crinkle V-Blade (**F**) in storage until it releases.




5. Remove crinkle V-Blade (**F**) from storage.




6. Raise bottom runway (**B**) and remove.




7. Remove slicing insert (**D**).




8. Open top runway (**C**).




9. Pull tabs to remove both julienne blades (**H**) and (**G**) from under deck storage.



10. Remove top runway (**C**).



11. Hand wash blades.




12. Wash all other parts in top rack of dishwasher.


Use & Care

GOOD GRIPS V-BLADE MANDOLINE


REASSEMBLY & STORAGE




1. Attach top runway (**C**).




2. While top runway (**C**) is open, attach both julienne blades (**H**) and (**G**) to under deck storage.




3. Close top runway (**C**).




4. Attach slicing insert (**D**).




5. Attach bottom runway (**B**).




6. Open bottom runway (**B**).




7. Place crinkle V-Blade (**F**) in under storage deck.




8. Close bottom runway (**B**).



9. Insert straight V-Blade (E).



10. Push button on dial and turn to lock position. Fold in legs.



11. Accessories available for purchase online.

INSTRUCTIONS FOR USE





Remove the Salad Spinner lid. The basket should rest inside of the clear bowl. Fill the basket with rinsed salad greens or fresh berries. Replace lid onto bowl.



Release the pump by sliding the lock away from the pump. The pump should pop up.



Press down on the pump and the basket will start spinning. Press the pump several times to ensure that the greens are dried.



Press the brake and the basket will come to a stop. Remove the greens from the basket.



Basket and bowl can be used separately for straining or serving. In addition, lettuce will stay fresh longer if stored in the basket inside the bowl, covered, and refrigerated.



To disassemble the lid for cleaning, turn the lid upside down and pull on the center plastic ring. To reassemble, push back on until you hear a click.

All parts are top rack dishwasher safe.