KobaGuard

SAFE BOX

INSTRUCTION MANUAL

Thank you for using KobaGuard safe box
Please read this manual first

1. SECURITY WARNINGS

1.1. Never put the mechanical key inside the safe box.
1.2. Do not use the mechanical key to open the safe regularly.
1.3. Always change the code with the door open and check the new code 3-4 times before closing.
1.4. It is strongly recommended to change the factory default code before using your new safe.

2. MAIN FEATURES

2.1. Solid arc welded heavy gauge steel construction.
2.2. 18mm solid steel bolts for maximum security and durability.
2.3. Powered by 4 x AA 1.5V batteries. Automatic low battery warning.
2.4. Digital display screen.
2.5. Internal carpet.
2.6. Rear and bottom mounting holes.
2.7. 3-6 digit guest code and 6 digit master code.
2.8. 5 minute system freeze on incorrect code entry (4 times).
2.9. Mechanical key override.

3. LOCK THE SAFE

- Enter any 3-6 digit code, then press the "LOCK(#)" key.
- CLOSED" will appear on the digital display, indicating that the safe is locked.

4. OPEN THE SAFE

4.1. Opening by personal code:
- Enter your 3-6 digit code.
- OPENED" appears on the digital display and the safe is opened.

KobaGuard

4.2. Opening by master code:
- Press the "LOCK"(#) button twice,
- SUPER" appears on the digital display,
- Enter the master code (factory setting "000000").
- OPENED" appears on the digital display and the safe is opened.

4.3 Opening with the mechanical key and resetting the guest code (in case both codes (master and guest) are forgotten):
- Open the security cover: turn it anticlockwise
- Insert the key and turn it clockwise
- The door opens
- While the digital display shows "OPEN", enter the new 3-6 digit code and press the "LOCK(#)" button.
- Remove the key

KobaGuard

5. CHANGING THE MASTER CODE

- Open the safe
- Press the CLEAR (*) button twice.
- PROG" appears on the digital display.
- When "PROG" disappears, enter the master code (factory code is 000000) within 5 seconds and press the "LOCK(#)" key.
- NEU" appears on the digital display.
- Enter the new master code (6 digits) and press the LOCK(#) button.
"DONE" will appear on the digital display, indicating that the new master code has been successfully set.

6. ADDITIONAL INSTRUCTIONS

6.1. Press "CLEAR(*)" button to clear the code if you have entered wrong digits.
6.2. "E-CODE" will appear on the digital display each time an incorrect code is entered. You can re-enter the code after the "beep" sound.
6.3. "HOLD-5" will appear on the digital display after 4 attempts to enter the wrong code and the safe will be locked for 5 minutes.
6.4. If the master code is forgotten
Press and hold the reset button inside the safe
Remove any battery to disconnect the power supply.
Replace the battery
"RESET" appears on the digital display
Master code is reset to factory default (000000)