beurer

FW 20 Cosy

OEKO-TEX®
CONFIDENCE IN TEXTILES
STANDARD 100
Special Articles
06.0.43510 HOHENSTEIN HTTI
Geprüft auf Schadstoffe.
Tested for harmful substances.
www.oeko-tex.com/standard100

EN Foot warmer
Instruction for Use

CE

ENGLISH

Contents

1. Items included in the package 3
   1.1 Description 3
2. Important instructions
   Retain for future use 3
3. Intended use 4
4. Operation 5
   4.1 Safety 5
   4.2 Initial use 5
   4.3 Switching on 5
   4.4 Setting the temperature 5
   4.5 Automatic switch-off 5
   4.6 Switching off 5
5. Cleaning and maintenance 6
6. Storage 6
7. Disposal 6
8. What if there are problems? 6
9. Technical data 6
10. Warranty / service 7

Explanation of symbols

<table>
<tr><td> </td><td>Read the instructions!</td><td> </td><td>Do not wash</td></tr>
<tr><td rowspan="2"> </td><td rowspan="2">Do not insert pins!</td><td> </td><td>Do not bleach</td></tr>
<tr><td></td><td>Do not tumble dry</td></tr>
<tr><td> </td><td>Do not use folded or rucked!</td><td> </td><td>Do not dry-clean</td></tr>
<tr><td> </td><td>Not to be used by very young children (0 - 3 years).</td><td rowspan="2"> </td><td rowspan="2">The textiles used for this device meet the stringent human ecological requirements of Oeko-Tex Standard 100, as verified by Hohenstein Research Institute.</td></tr>
<tr><td> </td><td>Dispose of packaging in an environmentally friendly manner.</td></tr>
<tr><td> </td><td colspan="3">WARNING: Warning of risks of injury or health hazards</td></tr>
<tr><td> </td><td colspan="3">CAUTION: Safety information about possible damage to appliance/accessories.</td></tr>
</table>

NOTE: Important information.

1. Items included in the package

1 Foot warmer
1 Fleece lining
1 Controller
1 Instructions for use



1.1 Description

1. Mains plug
2. Mains cable
3. Controller
4. Illuminated display for temperature settings
5. Sliding switch for ON/OFF and temperature settings

2. Important instructions Retain for future use

⚠ WARNING

- Non-observance of the following notes may result in personal injury or material damage (electric shock, skin burns, fire). The following safety and hazard information is not only intended to protect your health and the health of others, it should also protect the product. For this reason, pay attention to these safety notes and include these instructions when handing over the product to others.
- This foot warmer must not be used by people who are not sensitive to heat or by vulnerable people who may not be able to react to overheating (e.g. diabetics, persons with skin changes related to illness or persons with scarred skin in the area where the pad is to be applied, after taking any pain-relieving medication or alcohol).
- This foot warmer may not be used by very young children (0-3 years old) as they are unable to respond to overheating.
- This foot warmer may not be used by young children (3-8 years old) unless the controller has been set by a parent or responsible adult and the child has been given adequate instructions on how to use the foot warmer safely.
- This foot warmer may be used by children over the age of 8 and by people with reduced physical, sensory or mental skills or a lack of experience or knowledge, provided that they are supervised and

have been instructed on how to use the foot warmer safely, and are fully aware of the consequent risks of use.

- Children must not play with the foot warmer.
- Cleaning and user maintenance must not be performed by children unless supervised.
- This foot warmer is not designed for use in hospitals.
- This foot warmer must not be used to keep animals warm.
- Do not use this foot warmer with shoes.
- Do not insert needles.
- Do not use when folded or bunched up.
- Do not use if wet.
- The electrical and magnetic fields emitted by this foot warmer may interfere with the function of a pacemaker. However, they are still well within the limits: electrical field strength: max. 5000 V/m, magnetic field strength: max. 80 A/m, magnetic flux density: max. 0.1 millitesla.
  Please consult your doctor and the manufacturer of your pacemaker before using this foot warmer.
- Do not pull, twist or make sharp bends in the cables.
- Please check this foot warmer frequently for signs of wear and tear or damage.
  If any such signs are evident, if the foot warmer has been used incorrectly or if it no longer heats up, it must be checked by the manufacturer before being switched on again.
- If the mains connection cable of this device is damaged, it must be disposed of. If it cannot be removed, the device must be disposed of.
- The electronic components in the controller warm up when the foot warmer is in use. For this reason, the controller must never be covered or placed on the foot warmer when it is in use.
- Always observe the notes on operation (section 4), cleaning and maintenance (section 5) and storage (section 6).
- If you should have any questions about using our devices, please contact Customer Services.

3. Intended use

⚠ **CAUTION**

This foot warmer is intended only for heating human feet.

4. Operation

4.1 Safety

CAUTION

the foot warmer is fitted with a SAFETY SYSTEM. This sensor technology provides protection against overheating across the entire surface of the foot warmer with an automatic switch-off in the event of a fault. If the SAFETY SYSTEM has switched off the foot warmer, the temperature settings (4) are no longer illuminated when switched on. Please note that, for safety reasons, the foot warmer can no longer be operated after a fault has occurred and must be sent to the specified service address.

4.2 Initial use

Insert the mains plug into the socket.

4.3 Switching on

To switch the foot warmer on, set the sliding switch for ON/OFF and temperature settings to setting 1, 2 or 3. The temperature settings (4) are illuminated when switched on.

4.4 Setting the temperature

Level 0: OFF
Level 1: minimum heat
Level 2: medium heat
Level 3: maximum heat

NOTE:

The fastest way to warm up the foot warmer is to initially set the highest temperature setting.

NOTE:

This foot warmer has a fast heating function, which allows the foot warmer to warm up faster in the first 10 minutes.

WARNING

If the foot warmer is being used over several hours, we recommend that you set the lowest temperature setting on the controller to avoid overheating the feet, which may lead to burns to the skin.

4.5 Automatic switch-off

This foot warmer is equipped with an automatic switch-off function. This turns off the heat supply approx. 90 minutes after the initial use of the foot warmer. The temperature setting display then starts to flash. So that the foot warmer can be switched back on, the sliding switch for ON/OFF and temperature settings (5) must first be set to setting “0” (OFF). After about 5 seconds it is possible to switch it on again.

4.6 Switching off

To switch the foot warmer off, set the sliding switch for ON/OFF and temperature settings to setting “0” (OFF). The temperature settings are then no longer illuminated.

NOTE:

If the foot warmer is not in use, switch the sliding switch for ON/OFF and temperature settings to setting “0” (OFF) and unplug the mains plug from the socket.

5. Cleaning and maintenance

WARNING

Before cleaning, always remove the mains plug from the socket first.
Otherwise there is a risk of electric shock.

CAUTION

- The controller must never come into contact with water or other liquids, as this may cause damage.

To clean the controller, use a dry, lint-free cloth. Do not use any chemical or abrasive cleaning agents.

Small marks on the foot warmer can be removed with a damp cloth and, if necessary, with a little liquid detergent for delicate laundry.

CAUTION

- Please note that the foot warmer may not be washed, chemically cleaned, wrung out, tumble dried, put through a mangle or ironed. Failure to do so may damage the foot warmer.

The removable fleece lining is machine washable at 30°C on an extra-delicate cycle.

Use a delicate laundry detergent and measure it out according to the manufacturer's instructions.

WARNING

- Only use the foot warmer again once the foot warmer and fleece insert have fully dried. Otherwise there is a risk of electric shock.

6. Storage

If you do not plan to use the foot warmer for a long period of time, we recommend that you store it in the original packaging.

CAUTION

Please allow the foot warmer to cool down before storing. Failure to do so may damage the foot warmer.
To avoid breaking the foot warmer, do not place any objects on top of it whilst storing.

7. Disposal

For environmental reasons, do not dispose of the device in the household waste at the end of its useful life. Dispose of the unit at a suitable local collection or recycling point. Dispose of the device in accordance with EC Directive – WEEE (Waste Electrical and Electronic Equipment). If you have any questions, please contact the local authorities responsible for waste disposal.

8. What if there are problems?

Problem	Cause	Solution
The temperature settings are not illuminated while - the mains plug is connected to a working socket - the sliding switch is set to 1, 2 or 3	The safety system has switched the foot warmer off permanently.	Send the foot warmer for servicing.

9. Technical data

See the rating label on the foot warmer.

10. Warranty / service

In case of a claim under the warranty please contact your local dealer or the local representation which is mentioned in the list “service international”.
In case of returning the unit please add a copy of your receipt and a short report of the defect.

The following warranty terms shall apply:

1. The warranty period for BEURER products is either 3 years or- if longer- the country specific warranty period from date of Purchase.
   In case of a warranty claim, the date of purchase has to be proven by means of the sales receipt or invoice.
2. Repairs (complete unit or parts of the unit) do not extend the warranty period.
3. The warranty shall not be valid for damages because of
   a. improper treatment, e.g. nonobservance of the user instructions.
   b. repairs or tampering by the customer or unauthorised third parties.
   c. transport from the manufacturer to the consumer or during transport to the service centre.
   d. The warranty shall not be valid for accessories which are subject to normal wear and tear (cuff, batteries etc.).
4. Liability for direct or indirect consequential losses caused by the unit are excluded even if the damage to the unit is accepted as a warranty claim.

Subject to error and change

Beurer GmbH • Söflinger Str. 218 • D-89077 Ulm, Germany
www.beurer.com • www.beurer-healthguide.com

07.100.497_FW20_2018-11-12_01_IM2_BEU_EN