The GROOMI

GROOMI Brush Kit DIRECTIONS



Thanks fur your order!

Need help? Contact our pawesome team for support.
www.thegroomi.com
hello@thegroomi.com

Meet The Future of a Fur Free Home!

What You'll Get:

- GROOMI Mess Free Brush Kit
- Gentle Slicker Brush
- De-Shedder Brush
- Undercoat Rake Brush
- Flexible 1-Meter Hose
- Vacuum Adapters (Universal & Dyson)



Dyson Vacuum Compatibility Guide

Dyson Adapter

Fits any recent Dyson stick model 2017 onwards.

Compatible with V7, V8, V10, V11, V12, V15, Gen5detect, Gen5outsize models.





Own an older model Dyson? Extra adapters available to shop at www.thegroomi.com

V6 Adapter: Compatible with Dyson V6 and older models like DC19, DC23, DC26, DC29, DC31, DC33, DC35, DC37, DC39, DC41, DC45, DC47, DC52, DC54, DC58, DC59, DC62, DC78, and CY18.

Big Ball Adapter: Designed for CY22, CY23, and Cinetic Big Ball models (Multi Floor Extra, Allergy, Animal, and more).

Universal Vacuum Compatibility Guide



Universal Adapter

Fits any vacuum with a rounded outer diameter up to 45mm.

Compatible with LG, Samsung, Tineco, Miele, Ryobi, Kmart, Henry & more!*



Note: Is not compatible with vacuums that have an obscure, non-rounded shape. Example not compatible with Shark Stratos.



Groomi Brush Gentle Slicker

- Designed for Comfort & Safety
- Gentle On Sensitive Areas
- Reduces Matting & Tangles
- Ideal For Everyday Brushing
- Angled Bristles With Rubber Tips



Short Fur

Medium Fur

Long Fur

Groomi Brush De-Shed

- Great For Skin & Coat Health
- Removes Undercoat & Loose Fur
- Targets Dead Skin & Debris
- Preserves New Fur While De-Shedding



Short Fur

Medium Fur

Long Fur

Groomi Brush Undercoat Rake

- Safely Removes Loose Fur
- Suitable For Double Coats & Undercoats
- Reduces Tangles & Knots
- Great For Deep-Seated Fur
- Angled Comb



Medium Fur

Long Fur


1. Attach


2. Choose


3. Brush


4. Suck


Fur Free!

Directions

Step 1: Connect To Your Vacuum

Attach the Extension Hose to the bottom of the GROOMI Brush.

Dyson Directions:

For Dyson Stick Vacuums (2017 and newer): Connect the Yellow Adapter to the Extension Hose, then attach it to your Dyson.

Note: For Older Dyson Models (like V6 or Big Ball): You may need extra adapters (sold separately at www.thegroomi.com).

Universal Directions:

For Universal Vacuums (round connections up to 45mm): Attach the Extension Hose to the Black Stepped Adapter. Push and twist firmly for a secure fit.

Note: If the adapter doesn't fit snugly, you can trim the largest step off the rubber adapter using scissors or a blade for a clean finish.

Directions

Step 2: Pick Your Brush Head

Choose the brush head most suitable for your pet:

- Slicker (for everyday brushing)
- De-Shed (for removing loose fur)
- Rake (for deeper grooming)

How to Change Heads: Press the top brown button to release & swap the brush head.

Slicker



De-Shed



Rake



Directions

Step 3: Brush Your Pet

Brush your pet in the direction of their fur.
When fur collects on the brush, press the trigger on the handle. The fur will be sucked into your vacuum – no mess!

Vacuum Options: Keep your vacuum on while brushing for continuous fur removal.
OR
Brush with the vacuum off, then turn it on and press the trigger to suck up fur when needed.

When the vacuum canister is full, empty it and keep grooming if required.








The GROOMI



SCAN ME

Need help? Contact our pawesome team for support.
www.thegroomi.com
hello@thegroomi.com