Ruko®

3+
for age

User Manual

v2.0



6088

+1(888)892-0155 | Mon-Fri 7:00AM - 7:00PM (PST)

rukotoy.com

CONTACT US FOR MORE TECH SUPPORT

+1(888)892-0155 | Mon-Fri 7:00AM - 7:00PM (PST)

+1 (732) 207-0697 rukodrone@gmail.com

Content

1 Preparation Before Use 1

1.1 Romo APP Download Methods 1

1.2 Remote Control Battery Installation Instruction 1

1.3 Robot Recharging 2

2 Product Overview 3

2.1 Product Overview 3

2.2 Function Instruction 4

2.2.1 Frequency Pairing 4

2.2.2 Standby Mode/Wake-up Function 5

2.2.3 Gesture Sensing Function 6

2.3 Remote Control Function Button 7

3 Romo App 9

3.1 Bluetooth Connection 9

3.1.1 App Permission Setting 9

3.1.2 Connection 10

3.2 APP Control 11

3.2.1 Programming 12

3.2.2 QA Quiz Game 15

3.2.3 Encyclopedic Knowledge 17

3.2.4 APP Control 17

4 Appendix 19

4.1 Specification 19

4.2 Safety Disclaimer & Precautions 19

1 Preparation Before Use

1.1 Romo APP Download Methods

1. Download the Romo App by searching "Romo" in Google or Apple App Store.

2. Download the Romo App by scanning the QR code provided below.

(For Android)

(For iOS)

3. Supported System
   Android: 5.0 or later / iOS: 12.0 or later

1.2 Remote Control Battery Installation Instruction

1. Remote control requires 2 x 1.5V AAA batteries (Not Included) .


2. Use Philips screwdriver (Not Included) to open the battery cover on the bottom of remote control.

3. Assemble the batteries with correct polarity.

4. Install the battery cover by fixing the screw.

 Copyright ©2024 Ruko All Rights Reserved.

1.3 Robot Recharging



Self-equipped

1. Use 5V/2A charging plug (Not Included).
2. The robot takes about 2-3 hours to charge and about 2 hours to use.
3. The indicator lights up in red when charging, and the light goes out when charging is complete.


Charging Precautions


1. The robot cannot work while charging.
2. It is prohibited to charge the robot by using exceeding 5V/2A charger.
3. It is prohibited to overcharge the battery, please unplug the charging cable in time after fully charging.
4. Turn off the robot before charging and do not use the robot during charging.
5. Please use the original charging cable to charge the robot.

Copyright ©2024 Ruko All Rights Reserved.

2. Product Overview

2.1 Legends







- The remote control utilizes 2.4G signal, allowing for simultaneous play with multiple robots.

 Copyright ©2024 Ruko All Rights Reserved.

2.2 Function Introduction

2.2.1 Frequency Pairing

- Remote Control: The red light keep blinking after the battery is installed on the remote controller. That is the frequency pairing state. When frequency pairing completed, the red light will disappear (The robot transfers to the Standby Mode automatically when not in use).


- Robot: To turn on the robot, press the power button. The robot will light up and emit a sound. To turn it off, press the power button again.



Copyright ©2024 Ruko All Rights Reserved.

2.2.2 Standby Mode/Wake-up Function


- When the robot is in the power-on state and there is no operation for 10 minutes, it will automatically enter standby mode.
- Before entering standby mode, a voice will be played approximately once every minute.
- While in standby mode, the robot cannot be controlled by the remote control.
- Standby mode can last for approximately 30 days, so it is recommended to recharge the robot within the time frame.
- To wake up the robot, press the wake-up button once or press the on/off button twice.



 Copyright ©2024 Ruko All Rights Reserved.


2.2.3 Gesture Sensing Function

- The robot is capable of sensing gestures to move forward and backward, turn left and right.



Copyright ©2024 Ruko All Rights Reserved.

2.3 Remote Control Function Button



Note:

- The arms do not swing when the robot is sliding, but they do swing when the robot is walking.
- Volume adjustment have a total of 5 levels, default volume is mid-range volume.

TALK 1	Robot Voice×1	TALK 2	English Songs ×9
Music	Music ×3	TALK 3	Robot Language ×1
Song	Songs ×9		

 Copyright ©2024 Ruko All Rights Reserved.

Programming

- Press the program button on the remote control. The robot will beep twice, indicating that you can program the robot with up to 50 functions using the buttons on the remote control.
- After editing, press the program button again. The robot will then start to execute editing instructions.
- The 2 Mode Switch buttons, Volume+/Volume- button and STOP button do not participate in programming editing.

Memo

- Press the memo button, the robot will conduct the preset demonstration, total 3 demonstrations can be selected.


Copyright ©2024 Ruko All Rights Reserved.

3 Romo App


3.1 Bluetooth Connection


3.1.1 App Permission Setting

- iPhone: set App Bluetooth permission, select "OK".




- Android: set App permission, select "Allow".





 Copyright ©2024 Ruko All Rights Reserved.

3.1.2 Connection





- After clicking the connect button, it will automatically search for a connection and take you to the operation interface upon successful connection.



- If Bluetooth connection is unsuccessful, the interface shown above will appear. Check if both the cell phone Bluetooth and robot are powered on, and then attempt to reconnect.

Copyright ©2024 Ruko All Rights Reserved.

Attention

1. When the robot or Bluetooth is not connected, only the Encyclopedia Knowledge and QA Quiz Game in the app can be used.

2. The robot does not support the connection and control of multiple mobile phones at the same time.


3.2 APP Control

Operation Interface



 Copyright ©2024 Ruko All Rights Reserved.

3.2.1 Programming



Edit Action Bar

1. You can click the left and right arrows or slide the edit bar to turn the page.

2. Editable actions, emojis, music, English songs totaling 200.

Copyright ©2024 Ruko All Rights Reserved.

Edit Operation Display Area

① Long press the icon in the display area can drag the function command to arrange and edit it.



② Double-click the icon in the display area to delete individual function command.




 Copyright ©2024 Ruko All Rights Reserved.

Programming Example

- Example 1:
  If 2 consecutive emojis or music songs appear, they will be played in full before any further action is taken.




- Example 2:
  When editing a single emoji or music, the robot will execute the emoji, music, and action commands at the same time.



Copyright ©2024 Ruko All Rights Reserved.

3.2.2 QA Quiz Game

- 10 questions per round, click on the answer to automatically determine the score.



① The correct answer is indicated by a check mark and the system automatically moves on to the next question.



② To access the interface, answer at least 6 questions correctly. The robot will provide interaction action and sound.

 Copyright ©2024 Ruko All Rights Reserved.



③ If you answer a question incorrectly, your life value will decrease by one and you will automatically move on to the next question.



④ If you answer 5 questions incorrectly, your life value will be reduced to 0 and the interface will appear along with robot sound.


Copyright ©2024 Ruko All Rights Reserved.

3.2.3 Encyclopedic Knowledge

- On this page, you can choose to view Planetary Science and Earth Science.



3.2.4 APP Control



 Copyright ©2024 Ruko All Rights Reserved.

1	Slide	7/13	Speed Adjustment
2	TALK 2	8	Memo
3	Music	9	Volume +
4	TALK 3	10	Gravity-Sensitive Function
5	Songs	11	Stop
6	Walk	12	Volume -

Gravity-Sensitive Function

- Tap 

to enter the gravity sensing mode, you can tilt the phone forward, backward, left and right to control the robot's movements.



Copyright ©2024 Ruko All Rights Reserved.

4 Appendix

4.1 Specification

Remote Control	Batteries	2 x 1.5V AAA batteries
	Signal	2.4G
	Control Distance	about 30 meters
Robot	Use Time	2 hours
	Charging Time	2-3 hours
App	Control Distance	within 10 meters

4.2 Safety Disclaimer & Precautions

1. It is recommended to use alkaline batteries.
2. Do not mix new and used batteries, or mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
3. Batteries should be inserted or replaced by an adult, as they are small and can be easily swallowed.
4. Batteries should be inserted with the correct polarity and only use batteries of the recommended type.
5. Non-rechargeable batteries cannot be recharged, while rechargeable batteries are not recommended.

 Copyright ©2024 Ruko All Rights Reserved.

6. Before storing the product for an extended period of time, remove the battery. To prevent battery corrosion, inspect and replace batteries regularly.

7. Please ensure the supply terminals are not short-circuited.

8. Avoid exposing the battery to extreme heat or placing it in a fire.

9. If the wheels at the bottom of the robot become obstructed and cannot rotate, please clean them promptly.

10. Please save this information for future reference.

Copyright ©2024 Ruko All Rights Reserved.

rukotoy.com

CONTACT US FOR MORE TECH SUPPORT

+1(888)892-0155 | Mon-Fri 7:00AM - 7:00PM (PST)

+1 (732) 207-0697 rukodrone@gmail.com