21x9.5cm 双面印刷

EN

Soagrc

Low Voltage LED Net Lights

Model NO:
US:BG-CL3M3-306L01
EU:BG-CL3M3-306L01

soagrc@gmail.com

EN

Instructions for use:

1. Connect to power supply rst to ensure that the lights w ork before installing.

2. If lights do not turn on after the power is connected:
① Press the button on the adapter port.
② Press the ON button on the remote control.
③Check whether the timing mode indicator is on, turn off the timing mode, and repeat the preceding steps.

3. If there is still a problem, please contact Soagrc customer service with your Order Number. We'll behappy to help.

Specifications:

Material: Copper + Plastic

Dimension: 9.8ft×6.6ft(3m×2m)

Power cable length: 16.4ft(5m)

Color: Warm white/Cool white/Multicolor

LED quantity: 15×14（200 LED）

Waterproof grade: IP67

Maximum remote control distance: 16.4ft(5m)

Rated voltage: 29V(US)

Rated wattage: 6W

EN

Feature:

1. Standard Timing program gives you a set-and-forget function.

2. Operating with 29V/31V DC output voltage, it has excellent heat dissipation and is safe to the touch.

3. Eight (8)lighting modes to choose from.

4. Strands may be connected together (no more than 3 sets) and can be controlled by one controller or remote after connected.

5. Convenient memory and timer function:
① Memory function: The net light will always keep the last mode you set for next time use.

②Timer setting: Once the timing schedule has been set, changing the lights to various modes will not affect your timing schedule.

Operation:

1. Connect to the power outlet and link multi sets lights together if you need.

Guide to connect lights end to end:

① Find the end of one light set, and remove the lid.

②Remove the plug from another light set.

③Connect the two ends and then cover with the round 4 ring

2. Untie the string lights and hang them in place.

3. Connect the power supply.

4. Use the remote control or short press the button on the adapter to select the mode.

5. Function Description:
①ON:Turns on thestringlights

②Timer OFF:Turnsofftimer mode

③OFF:Turns off the string lights

3 Timer Setting

Pressthe**"4H""6H"or"8H"**buttonsontheremote control or press and hold the button on the adapter for a few seconds to switch to timer mode:

4H: 4 hours on, 20 hours off, the plug's timer mode indicator light is red.

6H: 6 hours on, 18 hours off, the plug's timer mode indicator light is green.

8H: 8 hours on, 16 hours off, the plug's timer mode indicator light is blue.

Press the "TIMER OFF" button on the remote control or press and hold the button on the adapter for seconds
and the light will cancel the timer mode.

8 Lighting Modes

1.C1 Steady ON:Warm white Steadyon
2.Slo-Glo: Slo-glo- Einzelne Leuchten verblassen langsam von hell zu dunkel
3.Sequential:Single light bead -ickering
4.In Wave:-Waving from bright to dim repeatedly
5.Chasing/Flash:Double light bead chasing and -ashing
6.Fade:Double light bead fade slowly from bright to dim repeatedly
7.Twinkle/Flash:Starry -ashing
8.Combination:Automatically convert every mode

4 levels of brightness

25%-50%-75%-100%

Please Note:

1. The remote has a battery included and pre-installed.

a) The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate."

b) The statement "Even used batteries may cause severe injury or death."

c) The statement "Call a local poison control center for treatment information."

d) A statement indicating the compatible battery type (e.g., LR44, CR2025).

e) A statement indicating the nominal battery voltage.

f) The statement "Non-rechargeable batteries are not to be recharged."
g) The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate, Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns."
h) The statement "Ensure the batteries are installed correctly according to polarity(+ and -)."
i) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries."
j) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations The statement "Always completely secure the
battery compartment. If the battery compartment does not cose securely, stop using the product, remove the batteries, and keep them away from children."

2. Replace the battery as illustrated below:



If you have any questions, please send us an email and we will handle them within 24 hours

MADE IN CHINA

DE

Soagrc

Niedervolt LED Lichternetz

Modellnummer:
US:BG-CL3M3-306L01
EU:LED light, TL2022

soagrc@gmail.com

DE

Gebrauchsanweisung:

1. Schließen Sie das Gerät vor der Installation an die Stromversorgung an, um sicherzustellen, dass die Lichter funktionieren.
2. Wenn die Lichter nach dem Anschließen an die Stromversorgung nicht angehen:
① Drücken Sie die Taste am Adapteranschluss.
②Drücken Sie die EIN-Taste auf der Fernbedienung.
③Überprüfen Sie, ob die Anzeige für den Zeitmodus leuchtet, schalten Sie den Zeitmodus aus und wiederholen Sie die vorhergehenden Schritte.
3. Wenn weiterhin ein Problem besteht, wenden Sie sich bitte unter Angabe Ihrer Bestellnummer an den Soagrc Kundendienst, Wir helfen Ihnen gerne weiter.

Spezifikationen:

Material: Kupfer + Kunststoff

Abmessungen: 3m*2m

Länge des Netzkabels: 5m

LED-Anzahl: 15*14

Farbe: Warmweiß

Wasserdichter Grad: IP67

Maximaler Fernbedienungsabstand: 5m

Nennspannung: 31V

Nennleistung: 6W

DE

Eigenschaften:

1. Das Standard-Timing-Programm bietet Ihnen eine Set-and-Forget-Funktion.

2. Das Gerät wird mit einer Ausgangsspannung von 31V DC betrieben, hat eine ausgezeichnete Wärmeableitung und ist berührungssicher.

3. 8 Modi zur Auswahl.

4. Stränge können miteinander verbunden werden (nicht mehr als 3 Sets) und können nach dem Anschließen von einem Controller oder einer Fernbedienung gesteuert werden.

5. Einfache Speicherfunktion:
①Modus speichern: Das Lichterkettenlicht behält immer den letzten Modus bei, den Sie für den
②Timer setting: Once the timing schedule has been set, changing the lights to various modes will not affect your timing schedule.

Operation:

1. Schließen Sie es an die Steckdose an und verbinde
Sie bei Bedarf mehrere lichter miteinander.
Anleitung zum Zusammenschalten zweier Leuchten:
①Suchen Sie das Ende einer Lichterkette und entfernen Sie den Deckel;
②Entfernen Sie den Stecker von einem anderen Leuchtenset.
③Verbinden Sie 2 Enden miteinander und decken Sie sie dann mit dem runden Ring ab.

2. Entwickeln Sie das Lichterkettenlicht.

3. Lösen Sie die Lichterketten und hängen Sie sie auf.

4. Verwenden Sie die Tasten am Adapter oder der Fernbedienung, um den Beleuchtungsmodus auszuwählen.

5. Bedienungsanleitung:
①ON: Licht einschlaten

②Timer OFF: Timer-Modus ausschalten
③OFF: Licht ausschlaten

3 Timer-Einstellung

Drücken Sie die Tasten **"4H" "6H" oder "8H"** auf der Fernbedienung oder halten Sie die Taste am Adapter einige Sekunden lang gedrückt, um in den Timermodus zu wechseln:

4H: 4 Stunden an, 20 Stunden aus, die Kontrollleuchte für den Timermodus des Steckers ist rot.
6H: 6 Stunden an, 18 Stunden aus, die Kontrollleuchte für den Timermodus des Steckers ist grün.
8H: 8 Stunden an, 16 Stunden aus, die Kontrollleuchte für den Timermodus des Steckers ist blau.
Drücken Sie die Taste "TIMER OFF" auf der Fernbedienung oder halten Sie die Taste am Adapter einige Sekunden lang gedrückt.
Anschließend bricht das Licht den Timermodus ab.

8 Beleuchtungsmodi

DE

1.Steady ON:Dauerlicht
2.Slo-Glo: Einzelne Leuchten verblassen langsam von hell zu dunkel
3.Sequential: Einzelne Leuchten -ackern
4.In Wave:Winkt wiederholt von hell nach dunke
5.Chasing/Flash: Doppelleuchten jagen und blinken
6.Fade: -Doppellampen dimmen langsam wiederholt von hell auf dunke
7.Twinkle/Flash: Sterne blinkt
8.Combination: Kon -vertiert automatisch jeden Modus

4 Helligkeitsstufe

25%-50%-75%-100%

Hinweise:

1. In der Fernbedienung ist eine Batterie enthalten und vorinstalliert.
2. Ersetzen Sie die Batterie wie unten dargestellt:



Achtung:

1. Um die Fernbedienung zu aktivieren, entfer nen Sie den in die Fernbedienung eingesetzten Schutzstreifen.

DE

2. Gewährleisten Sie, dass die Fernbedienung zum transparenten Punkt des Adapters zeigt.

3. Bitte lagern Sie die Lichterketten bei Nichtgebrauch an einem kühlen, trockenen Ort.

4. Seien Sie vorsichtig, dass Sie die Drähte beim Trennen oder Ausfahren nicht überdehnen , welches zu Beschädigungen führen kann.

5. Die Lichtquelle dieser Leuchte ist nicht ersetzbar; Wenn die Lichtquelle ihr Lebensende erreicht,muss die gesamte Leuchte ausgewechselt.

Soagrc

soagrc@gmail.com

If you have any questions, please send us an email and we will handle them within 24 hours

MADE IN CHINA

DE