IU-20 PROGRAMMING

ADDING USER CODE

✓ 1 ✓ Master code ✓ New user code ✓ New user code ✓

CHANGING MASTER CODE

✓ 2 ✓ Master code ✓ Master code ✓ New master code ✓ New master code ✓

CHANGING USER CODE

✓ 2 ✓ Master code ✓ Unwant user code ✓ New user code ✓ New user code ✓

DELETING USER CODE

✓ 3 ✓ Master code ✓ Unwant user code ✓

DELETING ALL USER CODE

✓ 4 ✓ Master code ✓

ENABLE EASY PASSAGE MODE

✓ 5 ✓ Master code ✓

DEDAULT MASTER CODE

123456

ENABLE ADVANCED PASSAGE MODE

✓ 0 ✓ Master code ✓ 1 ✓

DISABLE ADVANCED PASSAGE MODE

Master code ✓

DISABLE BEEPER

✓ 6 ✓ Master code ✓ 0 ✓

ENABLE BEEPER

✓ 6 ✓ Master code ✓ 1 ✓