Rav



Home Rav

Overview

The compact soundbar for music, TV, and more—

- Stylish listening setup, with the Sonos soundbar and Sub 4.
- Smart sound for cleaner speech—acoustic design allows you to set it in a credenza, mount it on a wall, or place it on a shelf.
- Stream music, podcasts, and more from your favorite services.
- Expandable. Add a full surround sound system, like Ray, Arc, or Beam (Gen 2).
- Control your Sonos system with the Sonos app for Android and iOS.
- The Sonos Sub mini is here to add Ray to your Sonos system.

Controls and lights



Volume control

Touch to raise (press bottom) or lower (press top) the volume.

- Volume up limit
- Volume down limit

Tip: Set a limit so you don't blow the ears of your TV fans.



Play/Pause

Touch to play or pause audio.



Back/Previous/ Forward

- Swipe right across the touch controls to skip to the next track.
- Swipe left across the touch controls to go back to the beginning of the current track. Note: You can't skip forward to a new track if there's a new station.



Status light

Displays the personalized set-up LED, application state like booting or restart, and system errors. Learn more

Connector panel



1	Line-in/Aux	Plug in to connect during setup.
2	AC power (sonos) input	Use only the supplied power cord during a Sonos power cord set up. Learn more
3	Ethernet port	Use to connect directly to your router. Learn more
4	Ethernet port	Use an Ethernet cable if you want to connect to a router, computer, or network attached storage (NAS) device (optional).

Select a location

You can mount Ray either on a shelf or below your TV, or place it on an AV stand.

TV stand (placement)

- Place Ray on a stable, level surface that is at least 4" (9.5cm) from the TV.
- Don't stack soundbars on top of one another.
- Don't block the TV's IR sensor.
- Leave at least 2" (5cm) on the left and right of Ray for optimal sound.
- Keep 1" (2.5cm) between Ray and the wall so you can reach the touch controls. For best sound quality, don't place Ray more than 3" (7.5cm) from the wall.

Ray's Sonos Mic isn't used to calibrate Ray.

Wall mount (placement)

You can mount Ray soundbar to a wall with a compatible wall mount. We recommend the custom-designed Sonos Wall Mount for the best placement options. See Wall mount for more instructions.

Connect the cables

Set the cables aside.

1. Connect the power cord to Ray's power port.

Tip: Use only the supplied power cord during a Sonos power cord set up.

2. Connect the Ethernet cable to your router or network switch.

Tip: Use only the supplied power cord during a Sonos power cord set up.



3. Plug the power cord into a power outlet.



4. Remove the protective cap, then connect the optical cable to your TV's optical digital port.



5. Remove the protective cap, then connect the optical cable to your TV's optical digital port.

(Tip) The optical adapter's port is "S/PDIF". Make sure the connector matches the port. Don't force it. Learn more about connecting to your TV's digital Ray cable.

Home theater

Sonos products like Ray and Sub Mini Wireless sound even better home theater. Create a more flexible system by adding Sonos Amp or Port.

Add a Sonos Amp

Use the Sonos app to adjust sound settings or change the way your Sonos home theater system works with your TV.

TV Setting Style

Only if TV sound is out of sync with the video, you can adjust the audio delay for optimal speech and settings. Learn more

Group Audio Delay

If you notice audio issues when playing in a group, you can adjust the setting. Learn more

TV Volume

TV Autoplay - Ray and Arc allow content playing when you turn on your TV. For example, when you turn on your TV, your favorite radio station starts playing in Ray's living room, or your TV channel is in your room's soundbar.

Night sound - Reduces the loudest sounds and enhances soft sounds and dialog, which makes late-night TV more enjoyable at lower volumes.

Speech enhancement - Makes dialog clearer so it's easier to follow what's happening.

Learn more

Speech enhancement

Night sound

Line-In

Sonos TV setup assistant - Guides you through the setup process.

Learn more

Sonos TV setup assistant

Set up surround speakers

Increase your sound immersion with surround speakers. Add Era 300 or Era 100 for Dolby Atmos soundbars. Or, connect right and left surround to your home theater.

Add surround speakers to your Ray soundbar and Sub for even better listening position, ranging from beautiful, immersive sound to...

1. Go to Settings > Systems.
2. Select your Ray soundbar > Surround Speakers.

Note: If you can't see the option, make sure your Ray soundbar and Sub are updated to the latest software version. Learn more about updates.

Learn more about setting up surround speakers

Surround speaker settings

During setup, surround sound is optimized for your room. These settings are adjustable:

Surrounds	Turn surround sound On or Off.
Test sound	Make sure your surrounds are working.
Mode Level	Select Ambient, Balanced, or Full Audio. Full Audio is the default. Learn more

Trueplay™

Ray's Automatic Trueplay tuning measures how sound reflects off walls, furniture, and other surfaces in your room and then tunes Ray's speaker to make sure it sounds great in your space.

Trueplay works on iOS mobile devices running iOS 14 or later. During tuning, you'll move around the room holding your iPhone.

1. Go to Settings > Systems and select your Ray soundbar.
2. Choose Trueplay Tuning and follow the prompts.

Learn more about Trueplay

Trueplay tuning is not available for Android devices that use Sonos Bluetooth connection. Trueplay tuning can't be applied to a Sonos Amp or Sonos Port that's driving your amplifier and speakers.

Product settings

You can customize the following settings in the Sonos app. Go to System and select a product.

Product Name	Give it the name you want to see from your user list page in the Sonos app.
Sync up/Split	Add a product to your group to sync up with it. Or, split it from a group.
Line-In	Select the product's name to change the input source. Learn more
TV	Select the product's name to change the input source. Learn more
Trueplay	Trueplay adapts the sound for your surroundings and content. Portable products can be Trueplay tuned. Learn more
Volume Limit	You can set a maximum volume for each user. Learn more
Volume Light	Displays the product's current volume by LED. Learn more
Touch Controls	Adjust the touch controls for volume, playback, and more. You can turn the touch controls on and off, and enable/disable adjusting playback or volume.
Battery Saver (portable products only)	To save battery life, you can set a schedule (weekdays, weekends, or both) for when the product's LED lights and touch controls are off.
Limit-In (home products with line-in capability)	When a product is portable, Sonos, or other audio device is connected to a product's line-in port, you can choose how it plays: • Sound check - Evens out the volume of different tracks. • Stereo Pair - Adjust the line-in source level if you find the default volume is too loud or too soft. • Audio Delay - Add a delay between the line-in source and Sonos so playback from the source sounds closer and in sync during video playback. • Enabled - Choose to turn Auto Play Line-In Audio On or Off to automatically start Sonos playback signal on the line-in port.

Accessories

Find the perfect accessory for your Sonos system—ranked in perfect fit and flawless performance. Browse accessories for your Ray soundbar, and see the accessories that work together.

Wall mount

Use the Ray wall mount kit (sold separately, available at sonos.com) for elegant flat mounting on a flat wall.

Guidelines

- Leave enough space between the top of your TV and your ear level if they touch normally.
- Don't mount Ray more than 3" (7.5cm) away from a wall. Sound is best when wall distance is optimized.

Mount kit contents

- Wall mount bracket
- Power cable clip (2 pcs)
- 2 wall anchors
- 2 wall screws

Wall mount kit (sold separately)

- Ray
- Phillips head screwdriver
- Power cord (supplied for installation location)
- Measurement tool
- Level
- Wall mount, optional

Wall mount	Ray (gen 2)	Ray (all products)	Ray (series)
Wood stud	16" / 40cm on	No	Yes
Drywall (no stud)	24.5" / 62cm on	No	Yes
Hard wallboard or double board	24.5" / 62cm on	Yes	Yes
Plaster	16.5" / 42cm on	Yes	Yes
Concrete or brick	24.5" / 62cm on	Yes	Yes

Set it up



1. Insert TV wall mount screws. Align the edge of the bracket with the bottom of the TV, leaving at least 2 inches of clearance below.

2. Mark the screw locations and remove the bracket.



3. Use the wall anchors, and a 5/16" drill bit to drill holes after getting wall studs to mark all. Then insert the wall anchors. Don't use wall anchors if you're mounting to drywall or plaster over brick. Mind wiring, electrical, and plumbing.

4. Position the wall mount bracket over the screw locations, using a level to make sure it's straight. Insert the wall mount screws and tighten them with the included Phillips head screwdriver. Leaving room for cables and connectors.

5. Using a Phillips head screwdriver, fasten the attachment screws to the back of the soundbar, making sure they are tight and secure.



6. Slide the soundbar down on the attachment screws to the top slots on the wall mount.

Make sure the screws are snug and the soundbar is level.



7. Route the cables down the attachment screws to the top slots on the wall mount.

Make sure the screws are snug and the soundbar is level.



8. Route the power cable through the cable clip and plug it into the outlet.



9. Route the Ethernet cable through the cable clip and plug it into the router.



10. Slide the soundbar down on the attachment screws to the top slots on the wall mount.

Make sure the screws are snug and the soundbar is level.

Specifications

Feature	Description
AUDIO	
Amplifiers	Four Class-D digital amplifiers
Drivers	Two mid-range woofers and two tuned tweeters for full-frequency playback in mid-range sound beyond the size limits. 3D tweeter.
Features	Two isolation modes to tune your sound for your room's acoustics
Audio ports	Two mono ports with proprietary and standard technology
Adjustable EQ	Use the Sonos app to adjust bass, treble, and loudness
AUDIO FORMATS	
Dolby Atmos	Yes, we've come with the best generation of the Sonos app.
Apple AirPlay 2	Works with AirPlay 2 to update devices iOS 11.4 and higher.
Formats	Bitstream pass-through supports the unique properties of the user's audio (DTS Digital Surround)
Speech enhancement	Turns on the Sonos tweeter when only the Sonos app to create TV dialogue more intelligible.
Night sound	Turns on the Sonos tweeter when only the Sonos app to ensure loud sounds are quiet.
Partner manufacturers	TV with optical digital audio output (broadband internet, and the Sonos app.
DIMENSIONS	
Dimensions (H x W x D)	2.76 x 35.43 x 5.12 in / 7 x 90 x 13cm
Volume	Mono, white
Mass	3.3 lb / 1.5 kg
Weight	3.3 lb / 1.5 kg
Speaker status light	Displays the product's current state in S/PP, indicates when the volume is muted and speech enhancement.
Operating temperature	32°F to 104°F (0°C to 40°C)
Storage temperature	-4°F to 158°F (-20°C to 70°C)
Control	Only your TV and product's IR remote control, touch controls on the Sonos app.
CPU	Broad Core, 1.2 GHz A35
Memory	1 GB DDR4L-2133
Mounting	Wall mountable housing bracket
POWER & CONNECTIVITY	
Power supply	Auto-switching, 100 VAC to 240 VAC at universal input
Wifi	Dual-band 802.11ac/a/b/g/n/ac with MIMO Range: 2.4 GHz broadcast capable
Optical	Use the included optical cable to connect the soundbar to your TV's optical digital audio output.
Ethernet	Plug and Play functionality to your router automatic
Supported devices	Android™ phone, Android™ tablet, iPad, iPhone, iPod touch
Supported devices	Compatible TV with optical cable. Plug-and-play compatibility with the TV, including cable box and satellite receivers.

- Specifications subject to change without notice.

Important safety information

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only dry cloth as cloth. Household cleaners or solvents can damage the finish on your Sonos product.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
9. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Unplug this apparatus during lightning storms or when unused for long periods of time.
12. The product does not have any user serviceable parts. Do not open or disassemble or attempt to repair it yourself. Doing so may void the product warranty. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
13. The Mute button controls the audio microphone (turned on or off).
14. **Warning:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
15. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.