ecozy

ICE MAKER

IM-BS260C | 12kg

User Manual

Thank you for purchasing our product.
If you have any questions or need further assistance,
please contact our customer service:
EU: support-eu@ecozy.com
UK / AE / SA: support@ecozy.com
Mon-Fri 9:00-18:00 (GMT+8)
(WEEK: Mon-Fri 9:00-17:00, 24.06-22.08, Monday to Friday)

ENGLISH	01-11
DEUTSCH	12-22
عربي	23-33

ENGLISH

Thank you for purchasing our product.
If you have any questions or need further assistance,
please contact our customer service:
EU: support-eu@ecozy.com
UK / AE / SA: support@ecozy.com
Mon-Fri 9:00-18:00 (GMT+8)
(WEEK: Mon-Fri 9:00-17:00, 24.06-22.08, Monday to Friday)

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS 01
PACKAGE CONTENTS 02
PRODUCT OVERVIEW 02
Ice Maker 02
Control Panel 02
BEFORE FIRST USE 03
1. Add Water 03
2. Select Ice Cube Size 03
3. Start/Stop Making Ice 04
4. Ice Full Reminder 04
5. Self-cleaning Mode 05
6. Water Drain 05
SPECIFICATIONS 06
TROUBLESHOOTING 07

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury during ice making operation, always read carefully and obey all safety information.

ALL SAFETY INFORMATION WILL FOLLOW THE SAFETY ALERT SYMBOLS BELOW

- SAFETY PRECAUTION — Important safety information.
- PROHIBITED MATTERS — Actions that are prohibited to prevent injuries or damage to properties.

- Read carefully these instructions.
- Use this ice maker only for its intended purpose as described in this manual.
- Do not use other liquids to make ice other than water.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or similar qualified persons in order to avoid a hazard.
- Ensure that the water power supply is 50-0 Hz and that AC 220-240V, 50Hz, 10A is used. Ensure that the power socket is grounded. Failure to do so may result in electric shock or fire.
- Ensure that the water power supply is 220-240V, 50Hz, 10A. Failure to do so may result in electric shock or fire.
- Ensure that the power cord is not damaged. Failure to do so may result in electric shock or fire.
- Ensure that the power cord is not twisted, bent, or pulled. Failure to do so may result in electric shock or fire.
- Ensure that the power cord is not crushed by heavy objects or pressed between the wall and other objects. Failure to do so may result in electric shock or fire.
- Ensure that the power cord is not near any heat source. Failure to do so may result in electric shock or fire.
- Ensure that the plug is not wet. Failure to do so may result in electric shock or fire.
- Ensure that the plug is fully inserted into the socket. Failure to do so may result in electric shock or fire.
- Do not use the ice maker if the power cord is damaged.
- Do not use the ice maker if the plug is loose.
- Do not pull the plug when unplugging it. Grasp the plug and pull it straight out from the socket.
- Do not use the ice maker if it is dropped or damaged.
- Do not use the ice maker if it is damaged or has been dropped.
- Do not use the ice maker if it is damaged or has been dropped.
- Do not use the ice maker if it is damaged or has been dropped