

## **Setting Descriptions (Notebook)**

1. Unscrew the screws on the bottom of your notebook.
2. Find and take out the original hard drive carefully.
3. Unscrew the adapter from hard drive and install it on the SSD.
4. Slide the SSD into the bay.
5. Screw the bottom of your notebook.

## **BIOS Setting**

(Reminder : The following is for reference only. Please refer to your notebook instruction.)

1. Restart your computer. It should recognize the SSD automatically.
2. Insert the OS set-up disk into your computer.
3. Before entering OS, pressing ESC, F1 or Delete to run the BIOS.
4. While in the BIOS, set the CDROM Boot Priority.
5. Save and exit BIOS.
6. Restart the computer, and install your OS.
7. Select boot from SSD in BIOS and complete the installation.