

CAW.CAR ACCESSORIES

MAGNETIC CAR MOUNT

INSTRUCTIONS

THIS CAR MOUNT USES HIGH-PERFORMANCE 3M®VHB® ADHESIVE. FOR BEST RESULTS, FOLLOW THESE INSTRUCTIONS CAREFULLY.

CAR MOUNT COMPONENTS SHOULD BE INSTALLED ON THE HARD SURFACE IN ROOM TEMPERATURE ENVIRONMENT (ABOUT 70°F [21°C]).

METAL DISCS INSTALLATION INSTRUCTIONS:

THE SMALLER DISC CAN BE ADHERED DIRECTLY TO THE BACK OF MOST PHONES OR OVER HARD CASES. THE BIGGER DISC CAN BE ADHERED UNDER A SLIM PHONE CASE. **DISCS ARE NOT MAGNETIZED**, JUST METAL. PRIOR TO USE THE MOUNT, TEST WHETHER THE FIXATION IS STRONG ENOUGH TO HOLD YOUR PHONE IN A CAR.

1. CLEAN THE BACK OF THE PHONE/CASE WITH THE ENCLOSED ALCOHOL PAD. **LET DRY.**
2. REMOVE THE ADHESIVE BACKING FROM THE METAL DISC.
3. POSITION THE DISC IN THE CENTER OF THE BACK OF THE DEVICE AND FIRMLY PRESS INTO PLACE.
- 3.1. IN CASE YOU USE A **WIRELESS CHARGER** PLEASE POSITION THE DISC NOT TO COVER THE QI CHIP.
4. WAIT ONE HOUR AFTER APPLICATION FOR SUFFICIENT CURE.



SMALLER AND BIGGER METAL
PHONE DISCS



METAL PHONE DISCS 3M®VHB®
ADHESIVE BACKING

DASHBOARD MOUNT INSTALLATION INSTRUCTIONS:

1. BEFORE REMOVING ADHESIVE BACKING, TEST THE POSITION OF THE MOUNT WITH PHONE IN A FEW DIFFERENT PLACES ON THE DASH. THE MOUNT SHOULD BE INSTALLED ONTO A **HARD & SMOOTH SURFACE** SUCH AS FLAT HARD PLASTIC, METAL, GLASS OR WOOD VENEER.
 2. CLEAN THE CHOSEN AREA WITH THE ENCLOSED ALCOHOL PAD. BE SURE TO **WAIT UNTIL DRY**, THE ALCOHOL CAN REDUCE ADHESIVE'S STICKINESS.
 3. PEEL THE ADHESIVE BACKING FROM THE MOUNT'S BOTTOM AND PRESS FIRMLY INTO PLACE FOR 10 SECONDS.
 4. **WAIT 24 HOURS** PRIOR TO USE TO ALLOW SUFFICIENT ADHESIVE CURE TIME.
- * IN COLD/HOT WEATHER INSTALL THE MOUNT IN A WARMED/COOLED CAR ONLY.



IMPORTANT MESSAGE TO CUSTOMERS WHO DON'T LIKE TO READ INSTRUCTIONS

WELL, WE LOVE YOU ALL THE SAME! JUST REMEMBER THESE CRUCIAL TIPS TO ENSURE THE SUCCESSFUL INSTALLATION:

1. INSTALL AT ROOM TEMPERATURE;
2. HARD & SMOOTH SURFACES ONLY;
3. DEGREASE THE SURFACE. WAIT TILL DRY;
4. PRESS FIRMLY FOR STRONGER BOND;
5. WAIT 24 HOURS BEFORE USE;
6. NEVER TOUCH 3M STICKERS WITH FINGERS.



ALTERNATIVE
FUN AND INTERACTIVE
INSTALLATION INSTRUCTIONS
BONUS INSIDE!



cawcar.com/guide

Scan me

REMOVAL INSTRUCTIONS:

1. APPLY A FEW DROPS OF RUBBING ALCOHOL (GOO GONE WORKS EVEN BETTER) BETWEEN THE MOUNT COMPONENT AND THE SURFACE IT HAS BEEN APPLIED TO IN ORDER TO BREAK THE ADHESIVE BOND.
2. CAREFULLY USE FISHING LINE OR DENTAL FLOSS IN A SAWING MOTION TO CUT FOAM AWAY FROM THE SURFACE (SEE ILLUSTRATION BELOW). USING YOUR FINGER, ROLL REMAINING ADHESIVE AWAY.



CAUTION! USE OF SHARP EDGES TO REMOVE ADHESIVE IS NOT RECOMMENDED, AS IT MAY RESULT IN SCRATCHES OR DAMAGE TO DEVICES AND/OR OTHER SURFACES!

DO NOT RE-USE 3M ADHESIVE. NEW ADHESIVES ARE PROVIDED IN A REINSTALL KIT INCLUDED TO A SET.

A REINSTALL KIT FOR THE MOUNT IS INCLUDED TO A SET.

TO REINSTALL, SIMPLY REMOVE ANY REMAINING ADHESIVE FROM THE INSTALLATION SITE, IF APPLICABLE. PLEASE ENSURE THAT ALL MOUNT COMPONENTS ARE FREE OF RESIDUAL ADHESIVE. USING YOUR FINGER, ROLL REMAINING ADHESIVE AWAY FROM APPLIED SURFACE. CLEAN ALL SURFACES WITH THE ALCOHOL PAD AND WAIT UNTIL DRY BEFORE INSTALLING NEW ADHESIVE DISC. TO ENSURE SUCCESSFUL REINSTALL, PLEASE TAKE CARE TO CENTER THE ADHESIVE DISC ON EITHER THE METALLIC DISC OR DASH BALL MOUNT.

ONCE SURFACES ARE CLEAN AND ADHESIVE HAS BEEN REINSTALLED, PLEASE REFER BACK TO STEP 1 OF THE INSTALLATION INSTRUCTIONS AND PROCEED THROUGH ALL OF THEM.

MAGNET WARNING – PLEASE READ

WHILE ITEM'S PHONE DISCS ARE JUST METAL (NOT MAGNETIC), THE MOUNT'S BASE CONTAINS A STRONG MAGNET. IT WILL NOT DAMAGE DEVICES WITH SOLID STATE DRIVES LIKE ANDROID PHONES, APPLE IPHONES, ETC.

HOWEVER, MAGNETS CAN DAMAGE SENSITIVE OBJECTS INCLUDING PACEMAKERS, COMPUTER HARD-DRIVES (INCLUDING IPOD PLAYERS HARD-DRIVES), CREDIT CARDS, MAGNETIC I.D. CARDS, AND OTHER SIMILAR ITEMS. CAW.CAR ACCESSORIES ASSUMES NO LIABILITY FOR DAMAGE TO SUCH OBJECTS.

CAW.CAR Accessories,
contact@cawcar.com

WWW.CAWCAR.COM

© CAW.CAR ACCESSORIES. ALL RIGHTS RESERVED.