

FREQUENTLY ASKED QUESTIONS

STEERING WHEEL COVERS

For detailed videos, please visit <https://help.carxs.com/>

carxs



HOW DO I INSTALL MY STEERING WHEEL COVER?

Safety First! Make sure your car is in Park with the parking brake engaged

1. Remove all attachments, ties, or wraps on your steering wheel
2. Place the steering wheel cover under the sun or somewhere warm. Our wheel covers are easier to install when the cover is warm. – You can also use a hairdryer to warm up the steering wheel cover. It will become more flexible and easier to wrap around your steering wheel.
3. Stretch out your steering wheel cover by pulling gently in opposite directions before installation. If your steering wheel has thumb rests or bumps at the 10 and 2 o'clock position please stretch the steering wheel cover a little extra at these points, it will make installation easier later on
4. Position the steering wheel cover over the wheel and gently work it on to your wheel with left to right movements. Try wrapping it over the top and using left and right motions to slowly cover the wheel.



HOW DO I CARE FOR MY STEERING WHEEL COVER?

1. We recommend removing your steering wheel cover and cleaning it with warm water and a little dish/hand soap. Make sure to let the steering wheel cover dry before installing it again.
2. We do not recommend using alcohol, spray cleaner, or other chemicals – they may damage the color and finish of your steering wheel cover

MY STEERING WHEEL COVER WON'T FIT, WHAT SHOULD I DO?

1. Please make sure you have the correct size steering wheel cover. Measure the side to side diameter of your steering wheel from outer edge to outer edge. Our steering wheel covers can fit a range of sizes. For our standard size covers they can fit steering wheels with a diameter of 14.5–15.5". Please check your steering wheel cover size to make sure your cover will fit.
2. If the size is correct, but the steering wheel cover is hard to stretch try placing the steering wheel cover under the sun or warming it with a hairdryer before installation. Also you can stretch it out gently before installation to make the material more flexible.



FITS
14.5" ~ 15.5"
DIAMETER
STEERING WHEELS