

3. After confirming that the floor mat is aligned with the inner contour of your car, press the floor mat until it fits completely.

Step 7: Repeat this procedure to install the other floor mats.

Warning

- Foxpark All-Weather Floor Mats are only suitable for vehicle specific model(s) and year(s). Please do not use them on vehicles of other brands, model(s) and year(s).
- Do not use the All-Weather Floor Mats in stunt cars or cars driving in competitive events, time-limited competitions, and high-performance driving schools.
- If the All-Weather Floor Mats become loose or move forward during driving, please stop your car and adjust the floor mats in a safe place, or remove the floor mats and put them in the trunk to ensure safety.
- Never install the floor mats upside down or turned over for any reason. Do not mix up the sides. Only install the driver's side floor mat in the driver's foot area; only install the passenger's side floor mat in the passenger's foot area.
- Do not trim Foxpark All-Weather Floor Mats.
- IF THE ALL-WEATHER FLOOR MATS ARE NOT INSTALLED CORRECTLY ACCORDING TO THE ABOVE INSTRUCTIONS, IT MAY CAUSE THE LOSS OF CONTROL OF THE VEHICLE AND DEATH OR SERIOUS INJURY.

If you have any questions about the floor mats during installation, please email service@foxpark.club

Foxpark

3D All-Weather Floor Mats User Manual



service@foxpark.club

Foxpark 3D All-Weather Floor Mats

Thank you for choosing Foxpark custom-fit floor mats for your Tesla. Foxpark mats are designed to safeguard your car's interior with their waterproof, sand-proof, and wear-resistant features. To ensure optimal performance, please follow the suggested installation and maintenance procedures outlined below.

Important:

Read all the installation instructions and the safety information before installing. Ensure that the mats do not obstruct the use of your vehicle's accelerator, brake, and clutch pedals after installation.



The All-Weather Floor Mats should be cleaned with wet towel or hose off. Do not use harsh chemicals or abrasive type cleaners, which may damage the mats.

Step 1: REMOVE ANY EXISTING CARPET OR FLOOR MATS and clear debris from your vehicle's floor.

Step 2: Place the floor mat in your car and align the bottom with the car's floor.

Step 3: Align the outside corner of the mat and gently press it into place.



(Step 2)



(Step 3)

Step 4: After aligning the outside corners, press along the bottom of the mat and gently press the inner side corner into place.

Step 5: Once the bottom and two corners are in place, **gently press** forward along the sides.



(Step 4)



(Step 5)

Note: Improper alignment may cause creases. If you experience improper alignment, do NOT forcefully press the mat. Remove the mat and adjust it again.

Step 6: Confirm that the floor mat is aligned with the inner contour of your car and press it down until it fits completely.



(Step 6)

Installation for Model 3 Passenger Mat:

1. Align the groove of the mat with the groove in your car's floor first.
2. After aligning the groove, gently press along the mat down to each of the four corners.



(1)



(2)