LOVEPEA Window Film Installation

Please use a hair dryer to soften the film or soak the film in warm water under cold weather.

The Most Important Tips

Note: Equipped tools are in a paper tube!











Take care to remove the protective film before use!

Installation Steps









Spray water to

both window

and film

Clean glass

Measure and cut

Peel off the backing film









7 Trim the edges



Wipe clean the surface of the film

Installation Kits

- √ Utility Knife
- √ Squeegee
- √ Spray Bottle



About Return And Refund

Please make sure to contact the seller FIRST in case you need to handle the return, defect item or other issues to prevent additional shipping costs from your side.

About Sharing



Your Product Review Is Biggest Support For Us.

Customer Service

LOVEPEA

