

**How to know that the kettle need to be descaled.**

*The unit turns off before the water comes to a boil*

**How to descale the Kettle.**

*Fill the kettle with water up to the 1.5 mark and bring to a boil. Next, add a small amount of white vinegar and let it sit for several hours. You can also use a commercial descaling product and follow the manufacturer's instructions. Rinse the kettle and the lime scale filter with clear water*

**How to clean and maintain the lime scale filter.**

*Remove the lime scale filter 8, soak it in a little vinegar, and then rinse clean with clear water*

**Things to check if lid is sticking.**

*In hard water areas this can be caused by a build-up of lime scale, follow steps listed as above.*

**What to do if the kettle not heating up.**

*Let the kettle 1 cool down for some time so that the appliance can be switched on*

**Can I turn off the kettle while it is heating up?**

*Yes, pressing the O ON/OFF switch again*

**What If the temperature cannot be set?**

*This indicates that the water in the kettle is hotter than the desired temperature. The current temperature will light up.*

**Is there anything I should do before I use the kettle for the first time?**

*Unroll the right amount of cable from the cable tidy and plug it in. Fill the kettle with water. Bring the water to a boil and discard it. Repeat the procedure. This will make sure that the kettle is clean for normal use. When the water comes to a boil for the first time, add a tablespoon of white vinegar*

*If you have concerns regarding the operation of this kettle please contact Bosch Customer Services product advice on 0844 8928920.*