

ITEM NO.: LS-82341

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack and place the lamp on a flat surface.
2. Insert the bolt (D) into the tube (C) and secure.
3. Put the tube (C) onto the base (E), make sure the bolt (D) goes through the hole of the base (E).
4. Attach the washer (F) and the nut (G) onto the bolt (D), using the wrench (H) to secure.
5. Insert bulb (A) into the socket.

Please note:

The height of the lamp can be adjusted. First, loosen ring (B) counter-clockwise, adjust the lamp to a suitable height, then screw the ring (B) and secure.

Use a 23W CFL Type bulb or 100W (Maximum) Incandescent A Type bulb.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully and easily inserted. Do not alter the plug.

※PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

