

If the machine cannot be turned on or cannot be charged, the problem with this radio should be that the battery is out of power, and the machine has entered the over-power protection state.

Please try the steps below,

Please remove all batteries, including the built-in rechargeable battery (bottom), leave them for 30 minutes, then plug the radio into the USB charging cable for charging 1 hour and see if it turns on? After that, reinstall the battery.