

Specifications

System requirements	For use with Xbox One systems and PCs running Windows 7 or later. Windows 10: requires Bluetooth, included USB cable, or Xbox Wireless adapter (sold separately). Windows 7 or 8.1: requires included USB cable; some functionality not supported. Drivers available at xbox.com/xboxone/PC-controller .
Xbox Accessories app requirements	Available on Xbox One and Windows 10 PCs.
Audio	Includes 3.5mm stereo headset jack. Also compatible with the Xbox One Stereo Headset Adapter and all other Xbox controller accessories made by Microsoft.
Haptic feedback	Features Impulse Triggers and rumble motors. Motor control can be adjusted in the app.
Weight	345g (+/- 15g) when using with 4 paddles, faceted D-pad, and standard thumbsticks attached.
Connectivity	Connect to Xbox One consoles with Xbox Wireless, or using the included 9' USB-C cable. Wirelessly connect to Windows 10 PCs and tablets using Bluetooth, or with the included 9' USB-C cable. Connect to Windows 7 or 8.1 PCs with the included 9' USB-C cable; some functionality not supported.
Thumbstick control	Use the included thumbstick-adjustment tool to manually change thumbstick tension, with 3 tension settings to choose from. Adjust thumbstick sensitivity curves with the Xbox Accessories app, or swap thumbstick inputs so that the left thumbstick controls the right thumbstick input and vice versa.
Battery	Internal, rechargeable battery with up to 40 hours of battery life per charge. Battery life varies with usage and other factors.
Assignable buttons	A, B, X, and Y; D-pad up, down, left, and right; Left and right bumpers; Left and right triggers; Left and right thumbstick click; 4 paddles.