

Trouble shooting steps

Step 1: Maybe the USB port has poor contact, try to unplug it and plug it in again.

Step 2: Check if there is something wrong with your computer's USB port, please try another computer port.

Step 3: Press FN + ESC to restore Factory Settings.

Step 4: Reboot your computer.