

Software Package PI-STAR V4.1.5



<https://drive.google.com/file/d/1pL8077KkEVoKuIXHsdQVQgsH3FY8CFZf/view?usp=sharing>

If your hotspot stopped working and stopped connecting to WiFi or Internet, or no longer call up the Configuration when no settings were changed. It would be just a glitch in the software on the MicroSD card. What you need to do is just reflashing the card using this package, and all will be well again. Before reflashing the card, please make an .img of the card after configuring your Pi-Star as a ready backup.

Note: The device uses the latest version of pi-star software V4.1.5. Our test device uses the DMR mode. When the device is started, a small font of pi-star is started successfully, and then disappears. Only waiting for you to connect to the walkie-talkie, the screen will display information , The system is the setting parameter of DMR mode, if you need other working mode, you need to change to your working mode