

8Bitdo Sn30 Pro+ Bluetooth Gamepad (Sn Edition) - Nintendo Switch
ASIN B07T8JKVNT

Functionality issue: Item defective or doesn't work ;

Solution: Please try to upgrade the firmware as follows:

- 1.Remove the battery first and then put it back in.
 - 2.Hold L+R+start for three seconds to start the controller.
 - 3.Download the firmware here: https://download.8bitdo.com/Firmware/Controller/SN30-Pro+/SN30_Pro+_Firmware_V3.01.zip
 - 4.Follow the steps in the firmware to run it.
 - 5.Restart the controller in the right mode to pair with your gaming device.
- Here is the detailed information - https://download.8bitdo.com/Manual/Controller/SN30-Pro+/SN30_Pro+_Manual.pdf

For more detailed information, please see its User Manual here :

For SN30 Pro+ controller:

https://download.8bitdo.com/Manual/Controller/SN30-Pro+/SN30_Pro+_Manual.pdf