

INSTRUCTIONS FOR USE

PLEASE READ ALL INSTRUCTIONS BEFORE USE SAVE THESE SAFETY INSTRUCTIONS.
Use only with scented wax melt. Not intended for use with fragranced warming oil or potpourri refresher oil.

WARNING: When using electric products, basic precautions should always be followed, including the following:

- Read all instructions before using the product.
- Do not put fingers or hands into wax warmer.
- Do not immerse in water.
- To reduce risk of injury, close supervision is necessary when used near children.

CAUTION: This Scented Wax Melt Warmer uses electricity. Risk of electrical shock exists if metal or any other foreign object is inserted into any of this electric wax melter or it is improperly used. Use only in properly functioning 120 AC electrical outlet. Do not add water to wax melter dish. Do not leave unit. Keep out of reach of children and pets.

Directions for Use:

- Place the warmer on a flat and heat resistant surface away from other heat sources and flammable objects;
- Place a piece of scented wax cube or tart in the bowl;
- Plug into a standard, functioning 120V AC electrical outlet and turn the switch on;
- Allow the heat to melt the wax and fragrance will release into the room.
- Wax Melter will become hot, please do not touch while in use. Heated wax can cause burns.
- If no wax remains in the bowl, turn the switch to off and unplug the electric tart warmer from outlet;
- DO NOT USE METAL OBJECTS TO CLEAN OUT WAX. THIS MAY CRACK AND DAMAGE BURNER. DO NOT PUT TART WARMER IN FREEZER.