

User Manual for AKB75095308 Replacement Remote Control

Overview

The AKB75095308 is a versatile replacement remote control designed for LG Smart TVs. Compatible with models from 2017 and later, this remote provides seamless control over your TV's features, including navigation of apps and menus.

Key Features

- **Compatibility**: Works with LG Smart TVs (2017 and newer models).
- **Full Functionality**: Includes buttons for power, volume, channels, streaming apps, and settings.
- **Point and Click**: Navigate menus and apps with a cursor controlled like a computer mouse.
- **Bluetooth Connectivity**: Ensures a reliable and responsive connection to the TV.
- **Battery-Powered**: Operates on two AAA batteries (not included) with extended battery life.

Compatible TV Models

The AKB75095308 is compatible with a wide range of LG Smart TVs, including but not limited to the following:

Full HD LED Smart TVs

- 32LJ610V, 43LJ610V, 49LJ610V
- 43UJ634V, 49UJ634V, 55UJ634V, 65UJ634V
- 43UJ6309, 49UJ6309, 60UJ6309, 65UJ6309
- 43LJ614V, 49LJ614V
- 43LJ624V, 49LJ624V

UHD LED Smart TVs

- 43UJ6307, 55UJ6307, 60UJ6307
- 43UJ630V, 49UJ630V, 55UJ630V
- 43UJ635V, 49UJ635V, 55UJ635V, 65UJ635V
- 43UJ6519, 55UJ6519, 60UJ6519, 65UJ6519

Specifications

- **Model**: AKB75095308
- **Battery Type**: 2 x AAA Batteries (not included)
- **Colour**: Black
- **Weight**: 62g

Package Contents

- 1 x AKB75095308 Replacement Remote Control

⚠ Batteries are not included in the package.

Setup Instructions

1. **Install Batteries**:

- Open the battery compartment on the back of the remote.
- Insert two AAA batteries, ensuring the correct polarity.
- Close the battery compartment securely.

2. **Pair with TV**:

- Turn on your LG Smart TV.
- Point the remote at the TV.
- The remote will automatically pair via Bluetooth. If it does not, refer to your TV's Bluetooth settings and select the AKB75095308.

3. **Test Functionality**:

- Press the Power button to confirm the connection.
- Navigate through apps and menus using the Point and Click cursor or other buttons.

Usage Tips

- ****Power Management****: Remove the batteries if the remote will not be used for an extended period to prevent battery leakage.
- ****Cleaning****: Use a soft, dry cloth to clean the remote. Avoid using liquid cleaners.
- ****Battery Replacement****: Replace both batteries simultaneously with new AAA batteries for optimal performance.

Troubleshooting

- ****Remote Not Responding****:

- Ensure the batteries are correctly installed and charged.
- Verify the TV's Bluetooth is enabled.
- Move closer to the TV to ensure a stable connection.

- ****Cursor Not Appearing****:

- Check if the Point and Click feature is enabled in the TV settings.
- Reset the remote by removing and reinserting the batteries.

Warranty Information

The AKB75095308 remote control comes with a standard warranty against manufacturing defects. For further details or support, please contact your retailer or visit the manufacturer's website.

Thank you for choosing the AKB75095308 Replacement Remote Control. Enjoy seamless and convenient control of your LG Smart TV!