

Important Safety & Usage Information

For PURA MAX 2

1. **Power and Operation:** Ensure the litter box is connected to the original PETKIT power adapter and placed on a stable, dry, and level surface. Do not use extension cords or third-party adapters. If power loss occurs, unplug the device, wait 5 seconds, and reconnect.

2. **Proper Use:** This device is designed for indoor use only and for cats weighing 1.5 – 8 kg (3 – 18 lbs). Do not use outdoors or in high-humidity environments.

3. **Sensor Maintenance:** Clean the infrared and weight sensors weekly with a dry cloth to prevent dust or litter buildup, which may affect sensor accuracy or cause detection failure.

4. **Scooping Performance:** For best cleaning results, use clumping cat litter and do not exceed the maximum litter level line indicated inside the drum. Avoid using crystal or non-clumping litter, as it may cause residue or incomplete cleaning.

5. **Device Care:** Avoid moving or lifting the device while it is operating. When relocating, hold the base firmly to prevent structural damage.

6. Troubleshooting:

If the device fails to scoop, check for foreign objects, excess litter, or sensor blockage. If you notice unusual noise or sparks, power off immediately and contact PETKIT Support.

7. **Material Caution:** Do not use corrosive cleaners or alcohol on the shell; this may cause cracks or surface damage.

8. **Customer Support:** For any issues, please contact support@petkit.com before returning the product. We provide technical assistance and replacement options.