

22000 Coffeemaker Help Guide

To get the most from your product and to avoid damaging it please read the instruction manual. Here are some key points.

Temperature

Filter coffee machine coffee do not produce boiling hot coffee because the optimum temperature for brewed coffee is around 86°C.

GROUND COFFEE

If you want to buy ready-ground coffee, medium-ground filter coffee will give you the best results.

DESCALING

Scale build-up will cause the element to overheat, reducing its working life. It will also lengthen the brewing time.

Descale regularly, at least once a month. If you notice the brewing time getting longer, shorten the time between descalings. In areas of very hard water, it may be necessary to descale more often, or to use filtered water instead of ordinary tap water.

Use a proprietary brand of descaler suitable for use in plastic-bodied products. Follow the instructions on the package of descaler. After descaling, run the appliance twice with fresh water, but without coffee, to rinse out any chemical residues.

TASTE ISSUES

Before using for the first time, fill the reservoir to the max mark and run the appliance without coffee. Let it cool, discard the water, then use it normally. If a taste issue develops then descale as explained above.