

Some Troubleshooting Steps

Customer can try the calibration steps below for stick drift issue.

Controller Calibration

- 1) Unplug the USB cable from the Windows PC (leave the cable plugged into the Enhanced controller)
- 2) Press and hold the Nexus, Menu, and View buttons simultaneously. While holding the three buttons down, connect the USB cable back into the USB port of the Windows PC
- 3) Once plugged in, the LED under the Nexus button will flash rapidly indicating the controller has successfully entered calibration mode. You may now release the three buttons
- 4) Rotate both analog sticks clockwise for three (3) complete rotations
- 5) Press both triggers simultaneously to the max distance and release three (3) times
- 6) Press the "D-PAD Down" and "Y" button simultaneously to save settings and exit the calibrate mode
- 7) Calibration is now complete
 - a. If calibration is unsuccessful, please repeat steps 1-6 above