

Troubleshooting Steps:-

- 1) Please go to the Drivers tab of CAM and select "Detect Devices". If you're using a CAM Beta version (4.0.x), just restart CAM instead.
- 2) Please exit out of CAM and install this Kraken driver <https://www.dropbox.com/s/kt dih3rif enohk4/Kraken%20chip%20Driver.zip?dl=0> then restart your PC and see if the LEDs display once the Kraken is detected in CAM again.
- 3) Go into Control Panel and click on "View Devices and Printers" then remove the NZXT USB Device/Unknown USB Device and restart your PC. Then check CAM and the LEDs again.
- 4) Try using a different MicroUSB cable, if you have a spare handy.
- 5) Try shutting off your PC, then plug the USB cable to a different USB header on your motherboard. Then, launch CAM, and see if the Kraken is detected. This will check to make sure the header you are using is not faulty.
- 6) Be sure you don't have any conflicting LED or fan control software running.