

[Wyze](#) > [Products](#) > [Lifestyle](#) > [Wyze Headphones](#)
> [Wyze Headphones Troubleshooting](#)

 Search

Wyze Headphones Troubleshooting

[My Wyze Headphones are not charging.](#)

[The microphone doesn't work when using an audio cable.](#)

[My charged headphones aren't turning on after removing from charger.](#)

[Wyze Headphones won't connect to Windows 10 via Bluetooth.](#)

[Audio quality is poor when I make a phone call.](#)

[Auto-pause isn't working on my Wyze Headphones.](#)

[My headphones audio is distorted, cutting out.](#)

[Voice quality is poor when using Zoom on PC](#)

[Alexa isn't working with Wyze Headphones](#)

[My Wyze Headphones are not connecting to the app. What should I do?](#)

[My headphones won't connect to Bluetooth.](#)

[Understanding your Wyze Headphones Status Light](#)

[How do I factory reset the headphones?](#)

[My headphones are not responding to touch controls](#)

Support

© 2023 Wyze Labs, Inc

Get Support



FAQ's

Returns & warranties

Help center

Get involved

Company

Join the community

About

Beta testing

Contact

Report a security vulnerability

Careers

Contact Us

Check out our **Contact Page**.



Terms of service | Privacy policy | Security & trust | California Notice of Collection