

Troubleshooting below;

- Ensure the hair is dry and combed through to remove any tangles. Divide the hair into sections ready for styling.
 - Rotate the temperature dial to turn the appliance on and to select a heat setting suitable for your hair type. The indicator light will flash until the selected temperature has been reached.
- Please note: Before styling make sure the universal heat glove is worn on the hand which is wrapping the hair around the barrel.
- Take a section of hair, starting 2 inches from the scalp and place the appliance next to the hair section, ensuring the end of the appliance is pointing down towards the shoulder.
 - Start winding the hair around the widest part of the barrel. Keep winding the hair down the length of the barrel until there is no more hair to wrap around.
 - Hold the end of the hair in place for 5-8 seconds, depending on your hair type. Then unwind or release the section of hair and pull the appliance away.
 - Allow the curl to cool before styling.
 - Repeat for each section of hair.
 - After use, rotate the temperature dial to the 'OFF' position to switch off and unplug the appliance.
 - Allow the appliance to cool before storing away. Heat Settings If you have delicate, fine, bleached or coloured hair, use the lower heat settings. For thicker hair, use the higher heat settings. It is suggested to always complete a test on initial use to ensure the correct temperature is used on the hair type. Start on the lowest setting and increase the temperature until desired result is achieved. Below is a guide of the temperature settings:

Auto Shut Off

This appliance has an automatic shut off feature for added safety. If the appliance is switched on for more than 72 minutes continuously, it will automatically switch off. If you wish to continue using the appliance after this time, simply rotate the temperature dial to the 'OFF' position and then to a heat setting suitable for your hair type to turn the power on again.

Heat Protection Mat

This appliance comes with a heat protection mat for use during and after styling. During use, do not place the appliance on any heat sensitive surface, even when using the heat mat provided. After use, switch off and unplug the appliance. Continue to keep out of reach of children as it will remain hot for several minutes.

Heat Protective Glove

IMPORTANT! A universal heat protective glove has been supplied to help protect the hand from temporary contact with the barrel when wrapping the hair around the appliance. The heat protective glove is only designed to give initial contact protection. Discomfort will be caused with prolonged contact with the hot surface.

OFF 1 = 150-160°C 5 = 160-170°C 10 = 170-180°C 15 = 180-190°C 20 = 190-200°C 25 = 200-210°C 30 = 210°C

CARE & MAINTENANCE

To help keep your appliance in the best possible condition, follow the steps below:

- Do not wrap the lead around the appliance, instead coil the lead loosely by the side of the appliance.
- Do not use the appliance at a stretch from the power point.

- Always unplug after use.