

## **Troubleshooting Steps**

- Please check polarity symbols on each battery pack prior to insertion to make sure they match against the symbols on your controller
- Each pack contains 2 x Controller Covers for Xbox One Generation and 2 x Controller Covers for Xbox Series X Generation – please ensure you select the correct cover for your controller
- To ensure a longer lifespan of your battery packs, we recommend charging to full capacity prior to initial use