

Thank you for purchasing this page turner.


They allow you to read e-books without having to hold heavy electronic devices in your hands all the time, especially in the cold winter when you can put your hands under a warm quilt or blanket.

The page-turner do not need to connect to Bluetooth and WIFI, and there are no complicated pairing steps. You can use them easily in 3 simple steps.

The page-turner support all capacitive touch screens, so they does not support older kindle.

Customer Service: **p-turner-service@outlook.com**

Product Introduction:



How to Use:

1. Press the page turner's switch once, and the blue indicator light will flash once.
2. Clip the page turner to the screen so that the metal contacts touch the screen.
3. Press the button on the RF remote control to turn pages.
4. After 8 minutes of not using the remote control, the page turner will automatically enter sleep mode. Press the switch of the page turner once to reuse it.

Working Indicator:

1. The indicators are all on the back and won't annoy you.
2. Each time you press the button of the RF remote control, the blue indicator of the remote control and page turner will flash once.
3. When the battery is low, the blue light will flash 3 times in a row as a prompt.

Charging Indicator:

1. The red light will stay on when charging, and it will automatically turn off after fully charged (about 1.5 hours).
2. If you use the page-turner to read e-books for 3 hours a day, you can

use it for 50-60 days on a full charge.

3. Please do not use high current chargers. The page turner can be charged through computer, power bank or cell phone charger.

About Pairing:

1. Our factory will pair the page turner, and you can use it directly after receiving the package.

2. If you need to re-pair, please press and hold the switch button of the page turner first, and after 3 seconds it will enter the matching state (the blue indicator will flash once and then stay on).

3. Then press and hold the button of the RF remote control, and after 3 seconds they will complete the pairing, and the blue indicator will turn off automatically.

Attention:

1. Built-in battery, keep away from fire.

2. After receiving the package, please make sure that there is no problem with the product first. We recommend that you charge them before using them.

3. The metal contacts of the page turner need to touch the screen, just the edge of the screen.

4. It can only be turned in one direction, when the page turner is on the

right, it turns to the next page; when the page turner is on the left, it turns previous page. Please avoid the top half of the screen (it will bring up the system menu bar).

5. Please adjust the margins of the text to avoid obscuring the text.

Packing List:

1 X RF Remote Control

1 X Page Turner

1 X Charging Cable

1 X Wrist Strap

1 X Storage Bag

After-sales Service:

1. We provide perfect after-sales service, if you have any questions, please feel free to contact us by e-mail.

2. **p-turner-service@outlook.com**

3. Just replace but not repair: If the product fails within 365 days, we offer a free replacement (except for man-made damage).