

# Remote Control User Guide

iJoy® 2580

**STOP/AUTO PARK** – stops the massage and parks the massage rollers at the top of the backrest.

**POSITION** – Use these buttons along with one of the stationary massage techniques to focus your massage on a specific area.

**MASSAGE TECHNIQUES** – Four massage techniques let you customize your massage.



**POWER RECLINE** – Effortlessly adjusts the backrest to a reclined or upright position.

**ZONE** – Targets your massage to a six-inch zone.

**AUTO MASSAGE PROGRAMS** – Select from three auto programs- which provide customized combinations of massage techniques-to refresh your entire back, relieve your neck and shoulders or release your lower back.

**POSITION** – Use this button to position the massage anywhere along your back.

For more detailed operation instructions, please see the Use and Care Manual.