

FAQ

How do I wash the cover and core of the breathable mattress?

Washing the Cover:

- Machine wash cold on gentle cycle. Use mild detergent and do not bleach. For best results, leave zipped.
- Tumble dry immediately on low heat. Dry thoroughly. Do NOT hang dry or iron. Do not dry clean.

Washing the Core:

- Recommend spot cleaning with a damp cloth for day-to-day cleaning.
- For large messes or big seasonal cleaning, core can be washed with soap and cool water. Hand wash in the shower or rinse outside with hose.
- Shake out excess water and stand up to dry. Place in a well-ventilated area for faster drying. Avoid drying in direct sunlight and do NOT use heat (i.e. hair dryer) to speed drying process.
- Ensure the core is completely dry before replacing cover.