

**Troubleshooting Steps:**

- Eject the disc and ensure it's clean.
- If you have another Xbox game disc, check that works to determine if it is a console or disc issue.
- If it is a disc issue, uninstall the game. You can keep the saved data installed.
- Make sure the console is connected to the internet, reinsert the disc & redownload the game.