

GET. SET.
PLAY.




Airdopes 121 Twin Wireless Ear-buds

Thank you for choosing boAt Airdopes 121, True Wireless Earbuds. Please think of this manual as your guiding map. Knowledge of Bluetooth and device connection is essential for operating the earbuds. Therefore, we strongly advise that this manual is thoroughly read before beginning use, and referred to when in times of difficulty.

Package Contents

- 1x Airdopes 121
- 1x Charging Case
- 1x Micro USB Charging Cable
- 1x Pair of Additional Earbuds (Small & Large)
- 1x User Manual
- 1x Warranty Card
- 1x Catalogue

Overview



Power On:

Step 1: Lay out the earbuds from the charging case. The earbuds will power on automatically.

Step 2: Press the MFB on either earbud for 2 seconds to power on the MFB (M/R) Function Button on both earbuds. The LED will start to blink red and green continuously.

Step 3: Press and hold the earbuds while both the earbuds automatically pair with each other and your smartphone. Repeat.

Note: -Once the earbuds are master earbuds, charging mode does not require. If the pairing time is missed then you'll need to reconnect the earbuds and follow the above mentioned procedure. -Airdopes 121 cannot use the previously connected device. Check which earbud the earbuds automatically reconnect with the previously paired device.



Connection Mode:


Step 1: Turn on Bluetooth on your device and then scan. (Transmission supported)

Step 2: Search for Airdopes 121 and pair accordingly. Enter "0000" as the pass key if available.

Step 3: Congratulations! Your Airdopes 121 is connected successfully. One earbuds LED starts to alternate flash. Red and the other earbuds LED starts to show single "S" symbol, once the connection is established.



LED Indicators / Functionalities



Single Earbud Usage

Step 1: Lay out the right earbud on its stereo mode and connected to Bluetooth device.

Step 2: Simply remove left earbud from your ear.

Step 3: Place the earbud back inside the charging case.

Step 4: Congratulations! You are now using single earbud mode.

Note: -Both the earbuds are master earbuds, single earbud usage will work on both the earbuds.

-To work in stereo mode, simply take out the earbud that has been kept inside. Put it on a Bluetooth device and pair with the other earbud. Congratulations for stereo usage.



Charge the Earbuds:

-Put the earbuds into the charging case in their correct orientation.

-A red LED on the earbuds will indicate they are being charged.

-This LED will turn blue and will turn off once the earbuds get fully charged.

-When both the earbuds are fully charged, the charging case will switch off its own power.

Warning: Please do not charge the carry case with 9V or "12V" output. Otherwise, it may cause damage to the case. Charge only according to the charging mode and power (5V, 2A).

-To charge the case, plug the provided micro USB cable into the charging case and connect to any USB port for any standard power source.

-The display inside the charging case indicates the charging/battery status percentage.

Basic Functions:

- Power On:** - Long press the MFB on either earbud for 2 seconds to activate voice assistant.
- Answering up phone call:** - Single press the MFB on either earbud to answer any incoming call and once again to hang up once done talking.
- Playing phone calls:** - Press earbud the MFB on either earbud for 1.5 seconds to reject an incoming call.
- Play/Pause:** - Single press the MFB on either earbud to play/pause music of your smartphone.
- Previous track:** - When playing music, double press the left earbud's MFB to go back to the previous track.
- Next track:** - When playing music, double press the right earbud's MFB to skip to the next track.

Note: The volume cannot be controlled via the earbuds. This may control the volume via the phone or music device.



Voice Assistant:

Step 1: Long press the M/R Function Button on either earbud for 2 seconds for earbuds to activate assistant.

Step 2: The respective voice assistant screen pops up and you may place your commands as usual.

Tip: Follow by the following commands:

- "What's the weather?"
- "Set a reminder"



Smart Power Off

-After usage, please remove the earbuds from your ears and place them back inside the case in correct orientation and close the lid of the case.

This will power off the earbuds and put them into charge.



Manual Power Off

Step 1: When in standby mode, long press the MFB on either earbud for 3 seconds to manually power off the earbuds. Please note that this will power off both the earbuds.

Step 2: Place them back inside the case to charge the earbuds and close the lid.

Factory Reset:

Perform the below steps in case you face any difficulty while operating your Airdopes 121.

Step 1: Place both the earbuds inside the charging case in their correct orientation.

Step 2: Triple tap the MFB on both earbuds to perform the factory reset. Once done, it gets back to standby mode and shows LED status.

Step 3: Shut the lid of the case and then reopen it again.

Step 4: Once you take the earbuds out from the case they automatically connect.

Congratulations! Your Airdopes 121 has been reset.



Common Problems with Solutions:

If only one earbud is functioning:



If only one earbud is functioning: Simply insert the earbuds back into the case and take them out again, perform the factory reset.

If earbuds are not in scan mode:



If earbuds not in scan mode: Simply put back both the earbuds in case and take out again or perform "Factory Reset".

Specifications

| Specification Type | Earbud Details |
|---------------------------|----------------------------------|
| Frequency | 2.4 GHz |
| Bluetooth | Bluetooth 4.2 (LE) |
| Audio Protocol/Decoder | SBC/AAC |
| Impedance | 16Ω ± 15% |
| Frequency Response Range | 20Hz - 20kHz |
| SNR | 90dB |
| THD | 0.1% |
| Maximum Output | 10mW |
| Max. Sensitivity | 108dB @1kHz |
| Earbud Weight | 2.5g ± 0.1g |
| Charging Time/Accessories | 1.5h (Full Charge) |
| Charging Case Weight | 25g |
| Charging Case Size | 45mm x 25mm |
| Charging Case Capacity | 100mAh (Full Charge) |
| Charging Case Material | ABS + PC (Full Charge) |
| Charging Case Color | Black |
| Charging Case Dimensions | 45mm x 25mm x 18mm (Full Charge) |
| Charging Case Weight | 25g (Full Charge) |
| Charging Case Capacity | 100mAh (Full Charge) |
| Charging Case Material | ABS + PC (Full Charge) |
| Charging Case Color | Black |

Charging norms & Precautionary Guidelines:

- 1) Charger/Block/Adapter
- 2) Cable/Wire

5V 2A Standard Cable (25 strands Ø0.10mm Diameter) strands Any other accessory can't be powered with this product as per the specifications and its per device norms.

Troubleshooting

| Problem/Issue | Solution |
|--|--|
| Right earbud is not working or not pairing | Check the earbud is fully charged. Insert the earbud into the case and close the lid. Wait for 10 minutes. Try again. If still cannot connect. |
| Left and right earbud are not pairing | To factory reset the device. |
| Right earbud does not work Bluetooth | Turn off the earbud and then turn on. |
| Unpaired earbud not working | Turn off the earbud and then turn on. |
| Earbud is not in scan mode | Put the earbud in the case, close the lid, and then take it out. If the earbud does not work, try performing the factory reset. |



Cautions:

- Please do not let the earbuds come into contact with sharp edges, solvent surfaces, and metal parts, as a polymer that can lead to some form of permanent damage or a cracked surface.
- Please don't disassemble the product in any way. It can lead to fire or other hazardous and cause completely damage the product. As this is a battery product, we ask that your professional handling of the earbuds is done only through a qualified service provider/manufacture etc.
- Please do not remove the battery by yourself. If it is a fault report to be managed by a service provider/manufacturer. Replacing the current battery with an old one can result in a fire or severe hazard. Therefore it is strongly advised against.
- Please clean the earbuds with the utmost of care with only a damp soft cloth. It is always to avoid. Please do not use any oily or alcohol liquid. In addition, ensure that the earbuds are kept away from extremely hot or cold conditions.
- To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level when you are listening to music. After listening the earbuds, gradually turn up the volume to a level where it is a comfortable listening level. Exposure to any noise levels at or above 85 dB can gradually lead to loss of hearing.
- Any damage to the earbuds that is not a manufacturing issue will mean the product is overused and you must. Please take the greatest care of your earbuds to ensure that they last for a long time.
- Do not use earbuds when it is unsafe to be wearing them, such as when operating a vehicle, crossing a street, or driving a car, in any where the awareness of your surroundings is required.