



USER MANUAL



Power Bank

Product Introduction

3 Outputs & One Input



- 1.UAB-A Port Output 1
- 2.UAB-A Port Output 2
- 3.LED Indicator Lights
- 4.USB-C Port PD Input/Output
- 5.Power ON/OFF

How to use

Power indicator switch

If you need to check the current remaining power of the product, you can tap this switch to light the LED display again to view the current remaining power of the product (if there is no other operation, the display will turn off again after about 35 seconds).

Specification

Product Name	POWER BANK
Model	HX160Y8
Battery Capacity	25,800mAh(95.46Wh)
USB C Input/Output	5V/3A
2 USB-A2 Output	5V/2.1A
Product Weight	18.5*76*156mm
Packing List	Power Bank*1, User Manual*1,USB C Cable*1

How to Charger Your Phone

Charge Through USB Outputs Ports:

Take out the charging USB cable that coming with your phone, connect the correct port to the power bank and your phone respectively.

How to Recharge the Power Bank

Recharge Through USB C Input Port

Please use the included charging cable to connect the usb c pd port of the power bank and an AC adapter or a power supply device with a USB-C jack(such as a PC)..

When charging, the 4 LED Indicator Lights show the current remaining power of the item (25%~50%~75%~100%), easily press the power button to turn it on or off.

Notice

- 1.The AC adapter is not included in the package.
- 2.For faster charging, please recharge the power bank using an adapter with 18W or higher power output.
- 3.The included charging cable is used to charge your devices or recharge the power bank.
- 4.When charging or discharging, some heat may be generated due to energy loss during transmission. This is normal.

Power Button Function

Press the power button once, the power bank will turn on and the 4 LED Indicators will light up to show the remaining battery percentage(25%~50%~75%~100%).

- Press the power button twice, the power bank will turn off and the Indicator lights will go out.

Important Safety Instructions

Please read below warm tips carefully before using the product.

- (1)Please store it out of the reach of little children.
- (2)Store product in a cool and dry place.
- (3)Do not store the product in hot or humid environments.
- (4)Do not dispose of the product in heat or fire.
- (5)Do not clean the product with harmful chemicals or detergents.
- (6)Misuse,dropping,or excessive force may cause product damage.
- (7)Operating temperature should be between 32°F to 113°F/0°Cto 45°C.
- (8)If the battery is hot or abnormal,please discontinue use immediately.
- (9)If the product is not being used a long time,it should be charged and discharged every three months.

(10)The product may feel warm when charging the device,which is a normal operating situation and should not be a cause for concern.

(11)The power USB interface of this product is specially used for charging and powering USB devices.Please do not use this product for other purposes.

(12)Do not disassemble the product.Take it to a qualified service person when repair is required.Incorrect reassembly may result in a risk of injury.