

USB C to HDMI Adapter User Manual

Please Read Before Use

1. Please use USB-C 3.1/Thunderbolt 3 cable! The female USB-C port of the adapter is for plugging in your Type-c cable, make sure your Type-c cable supports video transmission.
2. Not support HDMI to USB C ! Do not connect the HDMI port to your computer or laptop! The HDMI Port of the adapter only compatible with HDMI-enabled TVs/Monitors/Projectors.
3. When you use the USB C-HDMI adapter with USB hub, Please make sure your USB hub support video output, otherwise it won't work.

Usage:

1. Connect the HDMI port to your monitor/TV/projector.
2. And connect the male-to-male Thunderbolt 3/4 cable (USB C cable that supports video transmission) to the USB C female port of this adapter.
3. Finally connect the Thunderbolt 3/4 cable's connector to your laptop/phone.



Troubleshooting:

1. Using an improper cable(USB C cable version too low for video transmission).
2. Trying to convert in the opposite direction(Not HDMI input to USB C output).
3. The USB C port version of the phone is too low to transfer video. Make sure your phone's USB-C port supports video transfer.

Product quality guarantee

- 1. 100% computer + monitor test after welding completion**
- 2. 100% PC+Monitor test after molding**
- 3. 100% PC+Monitor test after molding the outer mold**
- 4. 100% appearance inspection**
- 5. 100% pass in FQC random inspection.**
- 6. 1 year warrant**

Compatible Devices(not a full list):

MacBook: MacBook M1 Pro (2021/2020/2019/2018/2017/2016), MacBook Air (Late 2018 and newer), MacBook (Early 2015 and newer)

iPad Pro (2021/2020/2018), iMac (Mid 2017 and newer), iMac Pro, Mac Mini (Late 2018 and newer)

Microsoft Surface Book 2, Surface Go, Google Chromebook Pixel (2015), Pixelbook, Pixel Slate

Dell Latitude 7373/5570/5490/5400 (2019), XPS 13/15

Samsung: Samsung Galaxy S22/S22+/S22 Ultra/S21/S21+/S21 Ultra/S20/S20+/S20 Ultra/S10e/S10/S10+/Note 20/Note 9/S8/S8+/S8 Ultra/S9/S9+


HTC 10/U Ultra/U11/U11+/U12+, Asus ZenFone/ROG Phone and more

Incompatible Devices:

Samsung: Samsung Galaxy A10/A11/A10e/A20/A20E/A50/A51/A70/A71/A80, Samsung S6/S7/J6/J7/M20/M30

OnePlus 2/3/3T/5/5T/6/6T, ALL Moto's phone, LG Stylo 4/5/6, LG V60, iPhone, Pixel phones

Others: Nintendo switch, GoPro, MacBook air 7.2, Samsung Galaxy Tab A/10.1/10.5, Galaxy Tab S3, Amazon Fire tablet, Kindle Fire



Instructions:

- 1: USB C Female port
- 2: HDMI A Male port
- 3: Double sided insert switch insert switch chip
- 4: PS176 Signal Converter Chip
- 5: PCB board